

**MC300 Prism Management Card**

# **User's Guide**

**6473040-03**

**Ver. 3, Rel. 0**

MC300 Prism Management Card User's Guide, 6473040-03, Ver. 3, Rel. 0, May 2003, Made in USA.

Quantum Corporation provides this publication "as is" without warranty of any kind, either express or implied, including but not limited to the implied warranties of merchantability or fitness for a particular purpose. Quantum Corporation may revise this publication from time to time without notice.

### **COPYRIGHT STATEMENT**

Copyright 2003 by Quantum Corporation. All rights reserved.

Your right to copy this manual is limited by copyright law. Making copies or adaptations without prior written authorization of Quantum Corporation is prohibited by law and constitutes a punishable violation of the law.

### **TRADEMARK STATEMENT**

Prism Storage Architecture is a trademark of Quantum Corporation.

Sun StorEdge L25 Tape Library and Sun StorEdge L100 Tape Library are trademarks of Sun Microsystems, Inc. in the United States and other countries.

Other trademarks may be mentioned herein which belong to other companies.

# Contents

---

---

<b>Preface</b>	<b>xi</b>
----------------	-----------

---

<b>Chapter 1</b>	<b>Prism Management Console</b>	<b>1</b>
	Determining the IP Address of the Library .....	1
	Accessing the Prism Management Console Web Pages .....	3
	Using the Prism Management Console Interface .....	4
	Home Page .....	5
	First Time User Account Setup .....	6
	Accessing Online Help .....	6
	Accessing the Sun Web Site .....	6

---

<b>Chapter 2</b>	<b>PMC Server Management</b>	<b>7</b>
	Network Configuration Page.....	8
	Accessing the Network Configuration Page.....	8
	Changing the PMC Network Configuration .....	9
	Date and Time Configuration Page .....	10
	Accessing the Date and Time Configuration Page .....	10
	Changing the Date and Time Information.....	11

User Management Page.....	11
Accessing the User Management Page.....	11
Adding User Accounts.....	12
Deleting User Accounts.....	14
Utilities Page.....	15
Accessing the Utilities Page.....	15
Uploading a New Software Image.....	16
Activating the New Software Image.....	17
Rebooting the PMC and Library.....	17
Shutting Down the PMC.....	18

---

<b>Chapter 3</b>	<b>ALERT E-mail</b>	<b>19</b>
------------------	---------------------	-----------

Contact Configuration Page.....	20
Accessing the Contact Configuration Page.....	20
Changing the Contact Configuration Information.....	22
Message Configuration Page.....	23
Accessing the Message Configuration Page.....	23
Viewing E-mail Recipients.....	24
Adding E-mail Recipients.....	25
Deleting E-mail Recipients.....	25
E-mail Configuration Page.....	26
Accessing the E-mail Configuration Page.....	26
Editing the E-mail Configuration.....	27
Sending a Test E-mail.....	28

---

<b>Chapter 4</b>	<b>ALERT Library Management</b>	<b>29</b>
------------------	---------------------------------	-----------

Library Status Page.....	30
Accessing the Library Status Page.....	30
Cartridge Movement.....	32
Library Physical View.....	32
Viewing Drive Status.....	33
Library Configuration Page.....	35
Accessing the Library Configuration Page.....	35
Changing BUS ID Settings.....	37
Library Statistics Page.....	38

Service Operations Page .....	40
Accessing the Service Operations Page .....	40
Performing a Library Self-test .....	41
Initializing Statistics.....	41
Uploading Library Firmware.....	42
Monitoring Configuration Page .....	43
Accessing the Monitoring Configuration Page .....	43
Setting the Monitoring Interval .....	43
Generating a Weekly Status Report .....	44
Event History Page.....	44
<hr/>	
<b>Chapter 5</b>	<b>Fibre Channel Management 47</b>
Cabling the FC420s to the PMC.....	48
Route Status.....	53
Bridge Status .....	55
Bridge Administration.....	58
Setting the Fibre Channel Data Rate .....	60
Setting the Fibre Channel Loop ID.....	60
Rebooting a Bridge .....	61
Uploading Bridge Firmware .....	61
<hr/>	
<b>Chapter 6</b>	<b>Getting Help 63</b>
<hr/>	
<b>Appendix A</b>	<b>Event Details Listing 65</b>
<hr/>	
<b>Appendix B</b>	<b>Regulatory Statements 95</b>
<hr/>	
<b>Glossary</b>	<b>97</b>
<hr/>	
<b>Index</b>	<b>101</b>



# Figures

---

Figure 1	Prism Management Console Home Page.....	4
Figure 2	Network Configuration Page.....	8
Figure 3	Date and Time Configuration Page.....	10
Figure 4	User Management Page .....	12
Figure 5	Edit Users Page .....	13
Figure 6	Utilities Page.....	15
Figure 7	Contact Configuration Page .....	20
Figure 8	Message Configuration Page .....	23
Figure 9	E-mail Configuration Page .....	26
Figure 10	Library Status Page.....	31
Figure 11	Element Information Page.....	33
Figure 12	Library Configuration Page.....	36
Figure 13	Library Statistics Page .....	39
Figure 14	Service Operations Page .....	40
Figure 15	Monitoring Configuration Page .....	43
Figure 16	Event History Page .....	45

## Figures

Figure 17	Cabling for a Single FC420 in an L25 .....	49
Figure 18	Cabling for a Single FC420 in an L100 .....	49
Figure 19	Cabling for Three FC420s in an L100 .....	50
Figure 20	Cabling for Two or More FC420s in Two or More L25s .....	51
Figure 21	Cabling for Two or More FC420s in an L100 .....	52
Figure 22	Route Status .....	54
Figure 23	Bridge Status .....	56
Figure 24	Bridge Administration .....	59
Figure 25	Home Page Help .....	64



# Tables

---

Table 1	PMC Default Network Settings .....	3
Table 2	Status Messages.....	5
Table 3	Network Configuration Page Field Descriptions.....	9
Table 4	Company Information.....	21
Table 5	Library Administrator Information .....	21
Table 6	Message Configuration Page Field Descriptions .....	24
Table 7	E-mail Configuration Page Field Descriptions.....	27
Table 8	Element Information Page Field Descriptions.....	34
Table 9	Library Configuration Page Field Descriptions .....	36
Table 10	Route Status Descriptions.....	54
Table 11	Bridge Status Descriptions .....	57
Table 12	Information Events Detail .....	65
Table 13	Warning Events Detail .....	75
Table 14	Failure Events Detail .....	81



# Preface

---

---

## **Audience**

This document is intended for use by customers who have purchased a Sun StorEdge™ L25 Tape Library or a Sun StorEdge™ L100 Tape Library and an MC300 Prism Management Card (PMC). Hereafter in this document, these libraries are referred to as L25 and L100, respectively.

This document assumes that the reader has a moderate level of general computer knowledge and server systems administration experience. This experience should include the installation of expansion cards as well as the administration of operating systems, Ethernet, and TCP/IP networks.

---

## **Purpose**

This document provides information about PMC options available, including:

- PMC Server Management
- ALERT E-mail
- ALERT Library Management
- Fibre Channel Management

---

## Document Organization

This document is organized as follows:

- [Chapter 1, Prism Management Console](#), explains how to access the Prism Management Console Web pages introduces the Prism Management Console interface and **Home** page.
- [Chapter 2, PMC Server Management](#), explains how to use the **PMC Server Management** Web pages: **Network Configuration**, **Date and Time Configuration**, **User Management**, and **Utilities**.
- [Chapter 3, ALERT E-mail](#), explains how to use the **ALERT E-mail** Web pages: **Contact Configuration**, **Message Configuration**, and **E-mail Configuration**.
- [Chapter 4, ALERT Library Management](#), explains how to use the **ALERT Library Management** Web pages: **Library Status**, **Library Configuration**, **Library Statistics**, **Service Operations**, **Monitoring Configuration**, and **Event History**.
- [Chapter 5, Fibre Channel Management](#), explains how to use the **Fibre Channel Management** Web pages: **Route Status**, **Bridge Status**, and **Bridge Administration**.
- [Chapter 6, Getting Help](#), explains how to access the online help for the Prism Management Console Web pages.
- [Appendix A, Event Details Listing](#), provides FSC codes and descriptions for **Information**, **Warning**, and **Failure** events.
- [Appendix B, Regulatory Statements](#), provides regulatory statements for the MC300 PMC.

This document concludes with a glossary and a detailed index.

---

## Document Illustrations

An L100 multiple library stack configuration was used for the illustrations in this document. The Prism Management Console screens that display on your system may vary from those shown in this document.

---

## System Requirements

The following minimum library firmware versions are required:

- Boot block version 3.00
- System code version 3.00

In addition, a network connection and browser software are required to manage the library from a remote location.

---

## Browser Support

Internet browser software is not supplied with the PMC. You must obtain and install a browser independently. The PMC supports the following Internet browsers:

- Netscape™ Communicator™ 4.78 and 6.2 or later

You can download this software from

<http://www.netscape.com>

- Microsoft® Internet Explorer® (IE) 5.5 or 6.0

You can download this software from

<http://www.microsoft.com>

Other versions of these products may be supported in future releases of the PMC software.

---

## Notational Conventions

This document uses the following conventions:

**Note:** Notes emphasize important information related to the main topic.

**Caution:** Cautions indicate potential hazards to equipment and are included to prevent damage to equipment.

**Warning:** Warnings indicate potential hazards to personal safety and are included to prevent injury.

## Related Documents

Documents related to the MC300 Prism Management Card, the L25, and the L100 are shown below.

### MC300 Prism Management Card, L25, and L100 Documentation

Document No.	Document Title	Description
6473042	<i>MC300 Prism Management Card Quick Reference Guide</i>	This document provides easy, step-by-step instructions for installation of the MC300 PMC in an L25 or L100 library.
6421029	<i>Sun StorEdge™ L25 Tape Library Unpacking Instructions</i>	This document explains how to remove the L25 library from the shipping carton.
6423014	<i>Sun StorEdge™ L100 Tape Library Unpacking Instructions</i>	This document explains how to remove the L100 library from the shipping carton.
6423015	<i>Sun StorEdge™ L25 Tape Library™ and Sun StorEdge L100 Tape Library Installation Guide</i>	This document explains how to install an L25 or L100 library.
6423016	<i>Sun StorEdge™ L25 Tape Library and Sun StorEdge™ L100 Tape Library User's Guide</i>	This document explains how to operate an L25 or L100 library.
6421031	<i>Sun StorEdge™ L25 Tape Library Regulatory Statements</i>	This document provides regulatory information for the L25 library.
6423018	<i>Sun StorEdge™ L100 Tape Library Regulatory Statements</i>	This document provides regulatory information for the L100 library.

Refer to the appropriate product manuals for information about your tape drive and cartridges. Use Adobe® Acrobat® Reader® 4 or higher to view the appropriate Portable Document Format (PDF) file.

### **SCSI-2 Specification**

The SCSI-2 communications specification is the proposed American National Standard for information systems, dated March 9, 1990. Copies may be obtained from:

Global Engineering Documents  
15 Inverness Way, East  
Englewood, CO 80112  
(800) 854-7179 or (303) 397-2740





## Chapter 1

# Prism Management Console

---

The MC300 Prism Management Card (PMC) is an intelligent server card that plugs directly into L25 and L100 libraries and is the enabling element for a variety of Prism options. The PMC consists of a single-board server powered by high-performance, industry-standard technology.

Included with the PMC is an easy-to-use yet powerful Web-based interface known as the Prism Management Console. It allows authorized personnel to configure and manage all Prism storage options from behind a firewall or remotely from anywhere on the Internet.

---

## Determining the IP Address of the Library

Before you can access the Prism Management Console Web pages, you must determine the IP address of the library.

By default, the PMC uses Dynamic Host Configuration Protocol (DHCP) to received its IP address; however, you can assign a static IP address manually if desired.

DHCP assigns the IP address based on the address range allowed by your network administrator. To determine the IP address assigned, go to the **DHCP Manager** window on the DHCP server. You can also obtain this information from the library graphical user interface (GUI) by selecting **Main > QuickView > Library > Network**.

If DHCP is not available on your network, the DHCP request times out after 30 seconds. The PMC then assigns itself the static IP address of 192.168.1.1.

**Note:** If the IP address 192.168.x.x is already used in the network, the PMC assigns itself the static IP address 10.0.0.x instead.

The **Subnet Mask** default is 255.255.255.0. If your subnet mask is different, you need to set up an isolated network, access the PMC, modify the PMC network configuration using the Prism Management Console Web pages, and add the PMC to the appropriate network.

**Note:** In some cases, you may need to temporarily configure a host computer's network configuration to the IP address 192.168.1.x, where x is some number between 2 and 254. Enter the subnet mask 255.255.255.0.

Using your browser, enter the IP address 192.168.1.1 to access the Prism Management Console Web pages. At this point, change the PMC network configuration to an appropriate IP address and subnet mask for your network.

If you still have problems accessing the IP address, contact your local system administrator for information on including the PMC in your network.

## Accessing the Prism Management Console Web Pages

To access the Prism Management Console Web pages:

- 1 On the host computer, open the Internet browser software.

**Note:** Internet browser software is not supplied with the PMC. You must obtain and install this software independently. See [Browser Support](#) on page xiii for a list of supported Internet browsers.

[Table 1](#) lists the default network settings for the PMC.


Table 1 PMC Default Network Settings

Field	Description
Use DHCP	Enabled
Hostname	PMC300-[MAC address]
Domain	[local domain]
IP Address	192.168.1.1
Subnet Mask	255.255.255.0
Default Gateway	[default or blank]

- 2 In the **Address** field of your browser, type the IP address for the PMC.

When the correct IP address for the PMC has been entered, the Internet browser displays the Prism Management Console **Home** page (see [figure 1](#)).

Figure 1 Prism Management Console Home Page



## Using the Prism Management Console Interface

The Prism Management Console interface (see [figure 1](#)) is divided into three sections:

- The Banner frame displays the Sun logo and software name. Clicking the Sun logo links you to the Sun web site.
- The Navigation frame lists the Prism Management Console web pages. To view a page, select its corresponding link.
- The Management frame displays the currently selected page. To return to a previous Prism Management Console page, click the Internet browser's **Back** button.

## Home Page

The Home page (see [figure 1](#)) indicates whether the library is ready for use. [Table 2](#) explains the significance of the status messages and status icon colors that may appear on the **Home** page.

Table 2 Status Messages

Status Message	Status Icon Color	Description
<b>Library is available</b>	Green	The library is ready for normal operation.
<b>Unable to communicate with library</b>	Red	A communication problem exists between the PMC and the library. Possible causes include a bad serial connection from the PMC to the library, or a conflicting baud rate* between the library and the PMC.
<b>Library is unavailable</b> — initializing — demo running — diagnostic running	Red	The library is not available to the host system for backup operations for one of the following reasons: <ul style="list-style-type: none"> <li>• It is in Standby mode</li> <li>• It is in Stop mode</li> <li>• It is initializing</li> <li>• It is in Demo mode</li> <li>• Diagnostics are in progress</li> <li>• SCSI communication is disabled</li> </ul>

\* The PMC communicates with the library at the library's default baud rate of 38400. To check or set the library baud rate, use the graphic user interface (GUI) on the library front panel.

---

## First Time User Account Setup

The first time you access another page from the **Home** page, you will be required to enter a user name and password.

**Note:** A default user name (**admin**) and password (**admin**) is assigned when you install the PMC.

**Caution:** To protect the integrity of your network and PMC access, it is recommended that you set up a new administration account when you begin using the PMC with your library. *After* this is accomplished, delete the existing admin account. Refer to [Adding User Accounts](#) on page 12 and [Deleting User Accounts](#) on page 14 for more information.

---

## Accessing Online Help

The Prism Management Console Web pages provide extensive online help files defining actions and terms for every function, feature, and field. To access these help files:

- Click the **Help** link at the bottom of the Navigation frame.  
A new Internet browser window opens and displays the first page of the online help files.
- Click the **Help** button at the bottom of the current Web page.  
A new Internet browser window opens and displays online help for the current Web page.

---

## Accessing the Sun Web Site

To access the Sun web site, click the Sun logo in the Banner frame of the **Home** page (see [figure 1](#)). A new Internet browser window opens and displays the Sun web site.

To return to the Prism Management Console Web pages, click the browser's **Back** button.

## Chapter 2

# PMC Server Management

---

PMC Server Management is managed through the following Prism Management Console Web pages.

- The **Network Configuration** page (see [page 8](#)) allows you to configure the hostname, domain, IP address, subnet mask, and gateway addresses.
- The **Date and Time Configuration** page (see [page 10](#)) allows you to set or adjust the date and time shown on the library.
- The **User Management** page (see [page 11](#)) allows you to set up users that are permitted access to the PMC and define their passwords.
- The **Utilities** page (see [page 15](#)) allows you to performance maintenance functions on the PMC, including software upgrades and rebooting the PMC system.

## Network Configuration Page

The **Network Configuration** page allows you to view or change the PMC network settings.

### Accessing the Network Configuration Page

To access the **Network Configuration** page, click **Network Configuration** in the Navigation frame, under **PMC Server Management**.

The Management frame displays the **Network Configuration** page (see [figure 2](#)).

**Note:** If the Internet browser displays a dialog box prompting you for your user name and password, type the information in the dialog box and click **OK**.

Figure 2 Network Configuration Page

The screenshot shows the Prism Management Card interface. The top banner reads "Prism Management Card". Below it, the page title is "PMC Server Network Configuration". On the left, a navigation pane lists: Prism Home, PMC Server Management (expanded), Network Configuration (selected), Date and Time Configuration, User Management, Utilities, ALERT E-mail, ALERT Library Management, and Help. The main content area is titled "View/Change PMC Network Configuration" and contains the following fields:

Use DHCP :	<input checked="" type="checkbox"/>
Hostname :	<input type="text" value="MyComputer"/>
Domain :	<input type="text" value="mycompany.com"/>
IP Address :	<input type="text" value="123.45.1.23"/>
Subnet Mask :	<input type="text" value="255.255.0.0"/>
Default Gateway :	<input type="text" value="123.45.0.1"/>

**Note:** If you select DHCP, the above settings will only apply in the event a DHCP server is unavailable.  
In order for these settings to take effect the PMC must be rebooted.

Buttons:

The **Network Configuration** page displays the current network configuration for the PMC. The fields are described in [table 3](#).



Table 3 Network Configuration Page Field Descriptions

Field	Description
<b>Use DHCP</b>	Enable <b>Use DHCP</b> if your network uses DHCP for dynamic IP addressing. If a DHCP server is unavailable, the other fields will apply. The default value is Enabled.
<b>Hostname</b>	This field displays the hostname for the PMC (for example, the DNS name). When entering a hostname, no spaces are allowed. Underscores are acceptable. The default value is PMC300-[MAC address].
<b>Domain</b>	This field displays the domain for the PC. The default value is [local domain].
<b>IP Address</b>	This field displays the IP address for the PMC. The default value is 192.168.1.1.
<b>Subnet Mask</b>	This field displays the subnet mask for the PMC. The default value is 255.255.255.0.
<b>Default Gateway</b>	This field displays the default gateway for the PMC. Change the value only as required by your network. The default value is [default or blank].

### Changing the PMC Network Configuration

To change the PMC network configuration:

- 1 Access the **Network Configuration** page (see [Accessing the Network Configuration Page](#)).
- 2 Edit the configuration information as desired.
- 3 Click **Apply**.

The PMC will not use the new basic configuration until it is rebooted. For more information, see [Rebooting the PMC and Library](#) on page 17.

## Date and Time Configuration Page


The **Date and Time Configuration** page allows you to set the date and time displayed by the library.

### Accessing the Date and Time Configuration Page

To access the **Date and Time Configuration** page, click **Date and Time Configuration** in the Navigation frame, under **PMC Server Management**.

The Management frame displays the **Date and Time Configuration** page (see [figure 3](#)).

Figure 3 Date and Time Configuration Page



This page displays the current date and time.

---

### Changing the Date and Time Information

To change the date and time information:

- 1 Access the **Date and Time Configuration** page (see [Accessing the Date and Time Configuration Page](#)).
- 2 Select the desired values from the **New Date and Time** list boxes.

**Note:** When entering information into the **Date and Time Configuration** fields, do not use decimals. If a decimal number is entered, only the whole number before the decimal is recorded.

- 3 Click **Apply**.

---

## User Management Page

The **User Management** page allows you to view, add, or delete user accounts. These accounts are used to control access to the Prism Management Console. Only users with accounts are allowed access to the Prism Management Console Web pages.

---

### Accessing the User Management Page

To access the **User Management** page, click **User Management** in the Navigation frame, under **PMC Server Management**.

The Management frame displays the **User Management** page (see [figure 4](#)).

Figure 4 User Management Page



The **User Name** section of the page lists the configured user accounts.


## Adding User Accounts

To add a user account:

- 1 Access the User Management page (see [Accessing the User Management Page](#)).
- 2 Under **Edit Users**, click **Edit**.

The Management frame displays the **Edit Users** page (see [figure 5](#)).

Figure 5 Edit Users  
Page



- 3 Under **Add User**, enter the new user account information:
  - a In the **User Name** field, type a unique user name.
  - b In the **Password** field, type the desired password.
  - c In the **Repeat Password** field, retype the desired password.

**Note:** Passwords are case sensitive.

- d Select the appropriate group from the **Group** list.  
The default groups are Administrator and Operator:
    - Administrator allows access to all functions of the PMC
    - Operator allows read-only access to the PMC
- 4 Click **Add**.  
A **Results** page indicates that the account has been added.
- 5 Click **OK** to return to the **Edit Users** page.

---

## Deleting User Accounts

To delete a user account:

- 1 Access the User Management page (see [Accessing the User Management Page](#)).

- 2 Under **Edit Users**, click **Edit**.

The Management frame displays the **Edit Users** page (see [figure 5](#)).

- 3 Under **Delete User**, highlight the user account you wish to delete.

- 4 Click **Delete**.

A **Results** page indicates that the account was deleted.

- 5 Click **OK** to return to the **Edit Users** page.

**Note:** The system does not allow you to delete the last existing administrator account. If the account needs to be deleted, create a new administrator account with the correct information *before* deleting the existing one.

## Utilities Page


The **Utilities** page allows you to perform maintenance functions on the PMC, including uploading and activating software images. The **Utilities** page also allows you to reboot the PMC.

### Accessing the Utilities Page

To access the **Utilities** page, click **Utilities** in the Navigation frame, under **PMC Server Management**.

The Management frame displays the **Utilities** page (see [figure 6](#)).

Figure 6 Utilities Page



## Uploading a New Software Image

To upload a new software image:

- 1 Access the **Utilities** page (see [Accessing the Utilities Page](#)).
- 2 Under **Upload New Software Image**, type the location and filename of the new software image.

**Note:** Click the **Browse** button to browse the system and locate the new software image. The file name for the new software image should begin with PMC300 and end with .image. An example of a valid image file name would be PMC300.[version].[build].image.

If the PMC does not recognize the new software image file as a valid software image, the transfer aborts.

- 3 Click **Upload** to place the new software image in a temporary area of the system.  
A **Results** page indicates that the software has been uploaded.
- 4 Click **OK** to return to the **Utilities** page.

**Note:** If you reboot the library before activating the uploaded software image, the image file is erased and the upload process must be performed again.

The PMC will use the new software image after it is activated and the PMC is rebooted (see [Activating the New Software Image](#) and [Rebooting the PMC and Library](#)).



---

### Activating the New Software Image

To move the uploaded software image from the temporary area, replace the current software image, and activate the new software image:

- 1 Access the **Utilities** page (see [Accessing the Utilities Page](#)).
- 2 Under **Activate New Software Image**, click **Activate**.

A progress bar indicates the progress of the software activation process.

**Caution:** The activation process takes several minutes. Do not interrupt the process; doing so may result in library failure and damage to the PMC.

- 3 When the progress bar indicates the activation process is complete, click **OK** to return to the **Utilities** page.

The PMC will use the new software image the next time it is rebooted (see [Rebooting the PMC and Library](#)).

---

### Rebooting the PMC and Library

To utilize updated configuration information, the PMC and library must be rebooted. To reboot the PMC and library:

- 1 Access the **Utilities** page (see [Accessing the Utilities Page](#)).
- 2 Under **Reboot PMC**, select **Reboot**, then click **OK**.

The PMC reboots itself, including restarting and initializing the library. If the library is part of a multiple library stack, all libraries in the stack will be restarted and initialized.

**Note:** Rebooting the PMC and library may take up to 15 minutes, during which time the library is unavailable. Before rebooting the PMC and library, ensure there are no active or pending jobs being processed by the library. It should not be necessary to reboot the PMC and library during normal operation.

---

## Shutting Down the PMC

Shutting down an L25 or L100 library while the MC300 PMC is in operation may cause the PMC image and/or configuration file to be corrupted. To prevent this from happening, follow this procedure whenever you must shut down a library with a PMC installed:

- 1 Access the **Utilities** page (see [Accessing the Utilities Page](#) on page 15).
- 2 Under **Reboot PMC**, select **Shutdown**, then click **OK**.

**Note:** Allow at least 3 to 4 minutes for the PMC to shut down.

- 3 Follow the standard procedure to shut down the library (see the *Sun StorEdge L25 Tape Library and Sun StorEdge L100 Tape Library User's Guide*, PN 6423016).

## Chapter 3

# ALERT E-mail

---

Prism ALERT E-mail is managed through the following Prism Management Console Web pages:

- The **Contact Configuration** page (see [page 20](#)) allows you to set up information about the company that owns the library and the primary and secondary contacts.
- The **Message Configuration** page (see [page 23](#)) allows you to set up the mailing lists for e-mail notification of various errors, failures, and activities.
- The **E-mail Configuration** page (see [page 26](#)) allows you to set up e-mail service information.

# Contact Configuration Page

## Accessing the Contact Configuration Page

To access the **Contact Configuration** page, click **Contact Configuration** in the Navigation frame, under **ALERT E-mail**.

The Management frame displays the **Contact Configuration** page (see [figure 7](#)).

Figure 7 Contact Configuration Page

**Prism Management Card**

**ALERT E-mail**  
**Contact Configuration**

**View/Change Contact Information**

Company Name :

Street :

City :

State :

Postal Code :

Country :

Library Location :

Support Contract :

**Primary**

Administrator :

E-mail Address :

Phone :

Fax :

Pager :

Street :

City :

State :

Postal Code :

Country :

**Secondary**

Administrator :

E-mail Address :

Phone :

Fax :

This page displays the contact information for the company and the primary and secondary library administrators.

The fields are described in [table 4](#) and [table 5](#).

Table 4 Company Information

Field	Description
<b>Company Name</b>	The name of the company for the installed library
<b>Street</b>	Street address where the library is installed
<b>City</b>	City for the above street address
<b>State</b>	State or territory for the above street address
<b>Postal Code</b>	Postal or zip code for the above street address
<b>Country</b>	Country for the above street address
<b>Library Location</b>	Location of the installed library within the facility
<b>Support Contract</b>	Support contract number for the library

Table 5 Library Administrator Information

Field	Description
<b>Administrator</b>	Person responsible for library administration
<b>E-mail Address</b>	E-mail address for the library administrator
<b>Phone</b>	Daytime telephone number for the library administrator, including area code
<b>Fax</b>	Business fax number for the library administrator, including area code

Field	Description
<b>Pager</b>	Pager number for the library administrator, including area code
<b>Street</b>	Business street address for the library administrator
<b>City</b>	City for the above street address
<b>State</b>	State or territory for the above street address
<b>Postal Code</b>	Postal or zip code for the above street address
<b>Country</b>	Country for the above street address

### Changing the Contact Configuration Information

To change the information shown on the **Contact Configuration** page:

- 1 Access the **Contact Configuration** page (see [Accessing the Contact Configuration Page](#)).
- 2 Insert or change the configuration information as desired.

**Note:** No spaces or quotation marks (“”) are allowed when entering telephone numbers or e-mail addresses. If spaces are entered, a message indicating `Illegal Phone Number` appears. Alphabetical characters, parentheses, and dashes are acceptable. An example of a correct telephone entry is (949) 555-1212.

- 3 Click **Apply**.

A **Results** page indicates the contact information has been saved.

- 4 Click **OK** to return to the **Contact Configuration** page.

## Message Configuration Page

The **Message Configuration** page allows you to control who receives message notifications. The message types are:

- Hardware Failure
- Configuration Change
- Operator Access
- Soft Errors
- Administrative

### Accessing the Message Configuration Page

To access the **Message Configuration** page, click **Message Configuration** in the Navigation frame, under **ALERT E-mail**.

The Management frame displays the **Message Configuration** page (see [figure 8](#)).

Figure 8 Message Configuration Page

Message Type	Add Recipient	Delete Recipient
Hardware Failure:	<input type="text"/>	Select Recipient ▾
Configuration Changes:	<input type="text"/>	Select Recipient ▾
Operator Access:	<input type="text"/>	Select Recipient ▾
Soft Errors:	<input type="text"/>	Select Recipient ▾
Administrative:	<input type="text"/>	Select Recipient ▾

Apply    Reset

[Table 6](#) describes the fields on this page.

Table 6 Message  
Configuration Page  
Field Descriptions

Field	Description
<b>Hardware Failure</b>	Errors or failures requiring onsite assistance or follow up, such as: <ul style="list-style-type: none"><li>• Tape drive failure detection</li><li>• Library control card failure</li></ul>
<b>Configuration Changes</b>	Change to the library or the PMC, such as: <ul style="list-style-type: none"><li>• Addition of new tape drive</li><li>• Changing the BUS ID of a tape drive</li></ul>
<b>Operator Access</b>	Operator access of the library, such as: <ul style="list-style-type: none"><li>• Accessing the magazine</li><li>• Opening a library door</li></ul>
<b>Soft Errors</b>	Errors or failures that do not require onsite assistance, but may lead to future problems, such as: <ul style="list-style-type: none"><li>• High temperature warnings</li><li>• Excessive positioning retries</li></ul>
<b>Administrative</b>	Regularly scheduled status reports, such as: <ul style="list-style-type: none"><li>• General status reports</li><li>• Test messages</li></ul>

## Viewing E-mail Recipients

To view e-mail recipients for a specific message type:

- 1 Access the **Message Configuration** page (see [Accessing the Message Configuration Page](#)).
- 2 If **SelectRecipient** is visible in the **Delete Recipient** field for the desired message type, click the down arrow.



The field displays a list of existing e-mail recipients for that message type.

**Note:** If **SelectRecipient** is not visible in the **Delete Recipient** field for the desired message type, there are no e-mail recipients configured for that message type.

---

### Adding E-mail Recipients

To add e-mail recipients:

- 1 Access the **Message Configuration** page (see [Accessing the Message Configuration Page](#)).
- 2 In the **Add Recipient** column next to the desired message type, enter the desired e-mail address.

To add multiple recipients, separate each e-mail address with a comma.

- 3 Click **Apply**.

A **Results** page indicates the e-mail recipient has been added.

- 4 Click **OK** to return to the **Message Configuration** page.

---

### Deleting E-mail Recipients

To delete e-mail recipients:

- 1 Access the **Message Configuration** page (see [Accessing the Message Configuration Page](#)).
- 2 Click the down arrow next to the **Delete Recipient** column of the desired message type.
- 3 Highlight the e-mail address you wish to delete.

**Note:** Only one e-mail recipient may be deleted at a time.

- 4 Click **Apply**.

A **Results** page indicates the e-mail recipient has been deleted.

- 5 Click **OK** to return to the **Message Configuration** page.

## E-mail Configuration Page


The **E-mail Configuration** page allows you to define the e-mail server information for the ALERT E-mail feature, and to send test messages. The information must be entered before any ALERT E-mail options will work.

### Accessing the E-mail Configuration Page

To access the **E-mail Configuration** page, click **E-mail Configuration** in the Navigation frame, under **ALERT E-mail**.

The Management frame displays the **E-mail Configuration** page (see [figure 9](#)).

Figure 9 E-mail Configuration Page



[Table 7](#) describes the fields on this page.

Table 7 E-mail  
Configuration Page  
Field Descriptions

Field	Description
<b>From E-mail Account</b>	<p>This field should contain a valid address on the e-mail server specified in the <b>Outgoing E-mail Server</b> field. The default account is Prism_Management_Console.</p> <p><i>Do not</i> add the domain name (@xxx) in this field.</p> <p>Not all e-mail server types require an account to be created. If you have problems, see your network administrator.</p>
<b>Outgoing E-mail Server</b>	<p>This field should contain the name of the server designated for outgoing e-mail, such as mail2.com</p>
<b>DNS Address</b>	<p>This field should contain the domain name server address, for example, 123.123.22.12.</p> <p>This is the IP address of your server providing DNS name resolution services.</p>

### Editing the E-mail Configuration

To edit the information displayed on the **E-mail Configuration** page:

- 1 Access the **E-mail Configuration** page (see [Accessing the E-mail Configuration Page](#)).
- 2 Edit the configuration as desired.
- 3 Click **Apply**.  
A **Results** page indicates the e-mail configuration has been saved.
- 4 Click **OK** to return to the **E-mail Configuration** page.

---

## **Sending a Test E-mail**

The **Test E-mail** option allows you to send a test message to verify that the e-mail configuration has been completed successfully. To send a test message:

- 1 Access the **E-mail Configuration** page (see [Accessing the E-mail Configuration Page](#)).
- 2 Under **Test E-mail**, click **Send**.

**Note:** The test message is sent to e-mail addresses in the Administrative E-mail list specified on the **Message Configuration** page.

## Chapter 4

# ALERT Library Management

---

The ALERT Library Management option is managed through the following Prism Management Console Web pages:

- The **Library Status** page (see [page 30](#)) allows you to view the general status of the library. It also allows you to move cartridges to various locations in the library or multiple library stack.
- The **Library Configuration** page (see [page 35](#)) allows you to view and set the BUS ID configuration of the library and drives.
- The **Library Statistics** page (see [page 38](#)) allows you to view specific information about the library and the number of times specific functions have been performed.
- The **Service Operations** page (see [page 40](#)) allows you to perform various service and status tests on the library and view the results.
- The **Monitoring Configuration** page (see [page 43](#)) allows you to set the monitoring and status report interval.

---

## Library Status Page

The **Library Status** page allows you to:

- View the status of the library
- Move cartridges within the library

---

### Accessing the Library Status Page

You can access the **Library Status** page in two ways:

- Click **Library Status** in the Navigation frame, under **ALERT Library Management**
- Click the status icon on the Prism Management Console **Home** page

The Management frame displays the read-only **Library Status** page (see [figure 10](#)).

**Note:** This page remains blank while the PMC queries the library for status. The page will go blank periodically while the information refreshes.

Figure 10 Library Status Page

**Prism Management Card**

**ALERT Library Management**  
**Library Status**

**Cartridge Movement** April 08, 2002 08:49 AM **READY**

From	Position	To	Position
Drive		Drive	

**Library Physical View**

12 bins available      12 bins available

12 bins available      12 bins available

12 bins available      12 bins available

12 bins available      12 bins available

11 bins available      12 bins available

11 bins available      11 bins available

12 bins available      12 bins available

12 bins available      12 bins available

**Frame 1**  
Serial Number: MD0206AHA00037  
Firmware Revision: ETC\_066  
Model Number: Sun Microsystems L100M

**Frame 1 - Level 4**

Drive		Elevator
1	2	1
Fixed Slot		Hand
1		1

This page is divided into two sections: **Cartridge Movement** and **Library Physical View**.

---

## Cartridge Movement

To move a cartridge within the library:

- 1 Select the source element for the cartridge to be moved:
  - a Open the **From** list and select the element type that contains the cartridge to be moved: *Drive, Bin, Port, Fixed Slot, Hand, or Elevator (shuttle)*.
  - b In the **Position** field immediately to the right of the **From** field, type the number of the element that contains the cartridge to be moved.
- 2 Select the destination element for the cartridge:
  - a Open the **To** list and select the element type for the destination element: *Drive, Bin, Port, Fixed Slot, Hand, or Elevator (shuttle)*.
  - b In the **Position** field immediately to the right of the **To** field, type the number of the source element.
- 3 Click **Apply**.

A **Results** page indicates that the cartridge has been moved.
- 4 Click **OK** to return to the **Library Status** page.

---

## Library Physical View

The **Library Physical View** section of the **Library Status** page provides detailed status for each library module, drive, fixed slot, bin, and elevator (shuttle). Bins designated as import/export elements are shaded.

**Note:** The Prism Management Console Web pages refer to each library module as a “frame.” Each library module is divided into levels. An L25 library module has one level, and an L100 library module has four levels, which are numbered from top to bottom. For more information about library levels, refer to the *Sun StorEdge™ L25 Tape Library and Sun StorEdge™ L100 Tape Library User’s Guide* (6423016).



## Viewing Drive Status

To view the status of a particular drive:

- 1 Access the **Library Status** page (see [Accessing the Library Status Page](#)).
- 2 In the **Library Physical View** section of the page, click the number of the drive for which you wish to view status information.

The Management frame displays the **Element Information** page (see [figure 11](#)), which displays status information for the selected drive.

Figure 11 Element Information Page




Table 8 Element  
Information Page Field  
Descriptions

Field	Description
<b>Address</b>	This field displays the hexadecimal address of the element.
<b>Barcode</b>	This field displays the barcode of the cartridge, if a cartridge with a barcode is in the drive. If a cartridge is present but does not have a barcode, <b>(Barcode?)</b> appears. If no cartridge is present, the field is blank.
<b>Type</b>	This field displays the element type being viewed.
<b>Bus ID</b>	This field displays the Bus ID of the element being viewed. (For SCSI devices, the Bus ID is the unique target of the device. For Fibre Channel devices, the Bus ID is the unique Loop ID of the device or "Soft" to indicate soft addressing mode.)
<b>Interface Type</b>	This field displays the element connection type (whether SCSI or Fibre Channel).
<b>Serial Number</b>	This field displays the serial number for the selected tape drive.
<b>Model</b>	This field displays the tape drive type, such as <b>DLT8000</b> .
<b>Revision</b>	This field displays the firmware revision number of the selected tape drive.
<b>Cleaning Needed</b>	If the tape drive is in need of cleaning, this field displays <b>Yes</b> . This is an informational message, permitting you to schedule the drive cleaning. If the condition is allowed to persist, the drive eventually moves to the <b>Cleaning Required</b> state and will not function until cleaning is performed.

Field	Description
<b>Cleaning Tape Expired</b>	If the cleaning cartridge in the drive has expired, this field displays <b>Yes</b> .
<b>Cleaning Required</b>	If drive cleaning is required, this field displays <b>Yes</b> . The drive will not function until cleaning is performed.
<b>Hardware Error</b>	If a hardware error is detected, this field displays <b>Yes</b> .
<b>Load Complete</b>	If the tape load is complete, this field displays <b>Yes</b> .
<b>OK to Operate Handle</b>	This field displays status and whether the handle is available for operation.
<b>Compression Enabled</b>	If compression is enabled, this field displays <b>Yes</b> .
<b>Cartridge Unloaded</b>	If the cartridge is unloaded but not ejected, this field displays <b>Yes</b> .
<b>Cartridge Ejected</b>	If the cartridge is ejected, this field displays <b>Yes</b> .

---

## Library Configuration Page

The **Library Configuration** page allows you to view or change the BUS ID settings for the library and drives.

---

### Accessing the Library Configuration Page

To access the **Library Configuration** page, click **Library Configuration** in the Navigation frame, under **ALERT Library Management**.

The Management frame displays the **Library Configuration** page (see [figure 12](#)).

Figure 12 Library Configuration Page




Table 9 Library Configuration Page Field Descriptions

Field	Description
<b>Device</b>	<p>This field lists the SCSI or Fibre Channel devices within the library, including the robotic controller and the drives. The library robotic controller is indicated by the device name <b>Library</b>.</p> <p>Drives may appear with <b>(Unfitted)</b> after their number indicating the drive is not present. BUS IDs can be set without the drive present.</p>
<b>Location</b>	<p>This field indicates the location of the device within the library module or multiple library stack. In a multiple library stack, the library module (frame) number is indicated.</p>

Field	Description
<b>Location</b> (continued)	Frame and level numbers are assigned from the top to bottom. For example, Frame 2-Level 5 indicates that the device is in the second library module and the fifth library level from the top of the multiple library stack.
<b>Interface</b>	Using the pull-down menu, the interface type can be selected. The two choices are SCSI and Fibre.  <b>Note:</b> The interface is obtained automatically for current fitted devices and can be set for future drives.
<b>BUS ID</b>	This field indicates the BUS ID of the device. For SCSI devices BUS ID is the unique target of the device. For Fibre Channel devices BUS ID is the unique Loop ID of the device or "Soft" to indicate soft addressing mode. <b>Note:</b> N/A will be displayed for unfitted devices.
<b>New BUS ID</b>	Using the pull-down menu, the BUS ID can be modified for either the library or the drives. Each device must have a separate and unique BUS ID for that topology. Each drive also displays its current BUS ID and allows you to assign a new BUS ID.

### Changing BUS ID Settings

To change the BUS ID of a device:

- 1 Access the **Library Configuration** page (see [Accessing the Library Configuration Page](#)).
- 2 Open the **New BUS ID** list box next to the device whose BUS ID you wish to change.
- 3 Select the desired **BUS ID** from the list.
- 4 Click **Apply**.

A **Results** page displays indicating the BUS ID was changed.

**Note:** BUS ID changes do not take effect until you click **Apply** and confirm the pop-up warning message.

**Caution:** Changing a BUS ID once your configuration has already been used by a backup software application or Fibre Channel bridge could render the configuration invalid.

---

## Library Statistics Page

The read-only **Library Statistics** page allows you to view specific information about the library and the number of times specific functions have been performed.

To view library statistics, click **Library Statistics** in the Navigation frame, under **ALERT Library Management**.

The Management frame displays the **Library Statistics** page (see [figure 13](#)).

Figure 13 Library  
Statistics Page



The **Library Statistics** page displays the following statistical information for each magazine, drive, fixed slot, and shuttle (elevator) in the library or multiple library stack:

- Power On Hours (does not reset upon initialization)
- Good Fetches
- Fetch Retry 1
- Fetch Retry 2
- Fetch Retry 3
- Good Stows
- Stow Retry 1
- Stow Retry 2
- Stow Retry 3

- Scan Retries
- Scan Count

---

## Service Operations Page

The **Service Operations** page allows you to perform tests and view the results.

---


### Accessing the Service Operations Page

To access the **Service Operations** page, click **Service Operations** in the Navigation frame, under **ALERT Library Management**.

The Management frame displays the **Service Operations** page (see [figure 14](#)).

---

Figure 14 Service Operations Page





---

## Performing a Library Self-test

To perform a self-test on the library:

- 1 Access the **Service Operations** page (see [Accessing the Service Operations Page](#)).
- 2 In the **Selftest** section of the page, select the test to be performed.

The available tests are:

- **Check X-Axis Friction**
- **Check Y-Axis Friction**
- **Check Z-Axis Friction**
- **Check Picker-Axis Friction**
- **Check Theta-Axis Friction**
- **Check Elevator-Axis Friction**
- **Check X-Axis Sensor**
- **Check Y-Axis Sensor**
- **Check Picker-Axis Sensor**
- **Check Theta-Axis Sensor 1**
- **Check Theta-Axis Sensor 2**
- **Check Elevator-Axis Sensor**

- 3 Click **Apply**.

A **Results** page indicates the self-test is complete.

- 4 Click **OK** to return to the **Service Operations** page.

---

## Initializing Statistics

To initialize the statistics functions of the library:

- 1 Access the **Service Operations** page (see [Accessing the Service Operations Page](#)).
- 2 In the **Initialize** section of the page, select **Statistics**.
- 3 Click **Apply**.

A **Results** page indicates the initialization, or reset, is complete.

- 4 Click **OK** to return to the **Service Operations** page.

---

## Uploading Library Firmware

To upload library firmware:

- 1 Access the **Service Operations** page (see [Accessing the Service Operations Page](#)).
- 2 Click **Browse** to locate the appropriate image file on the host computer.

**Caution:** Before you perform the upload, make sure there are no processes or applications accessing the library. If there are, shut down the process or application, or pause the operation, until the upload completes.

**Warning:** Make sure the image file is valid; otherwise, you may render the library unusable after the upload.

- 3 Click **Upload** to begin the library firmware upload.

**Caution:** The entire upload process may take up to 45 minutes to complete. **Do not interrupt the process.** Wait for the upload to finish. At the end of the upload, the library automatically resets itself.

During the firmware upload process, a progress window displays, indicating the current operation being performed to complete the firmware upload process.

In a multiple library stack, the master library module is updated first, then the succeeding library modules.

## Monitoring Configuration Page


The **Monitoring Configuration** page allows you to set the monitoring and report interval.

### Accessing the Monitoring Configuration Page

To access the **Monitoring Configuration** page, click **Monitoring Configuration** in the Navigation frame, under **ALERT Library Management**.

The Management frame displays the **Monitoring Configuration** page (see [figure 15](#)).

Figure 15 Monitoring Configuration Page



### Setting the Monitoring Interval

To set the monitoring interval time in minutes:

- 1 Access the **Monitoring Configuration** page (see [Accessing the Monitoring Configuration Page](#)).
- 2 In the **Monitoring Interval** section of the page, type the desired number of minutes between monitoring.

The monitoring determines the polling frequency for library configuration changes. The interval entered must be between 0 and 60 minutes.

**Note:** The default monitoring interval is 5 minutes. If the monitoring interval is changed to 0 (zero) minutes, no library configuration changes are reported, and no configuration change e-mails are sent.

**3** Click **Apply**.

A **Results** page indicates the monitoring interval information has been saved.

**4** Click **OK** to return to the **Monitoring Configuration** page.

---

## Generating a Weekly Status Report

To specify when to generate a weekly status report for the library:

**1** Access the **Monitoring Configuration** page (see [Accessing the Monitoring Configuration Page](#)).

**2** In the Weekly Status Report section of the page, select the desired day, hour, minute, and AM or PM.

**3** If the status report is to be sent automatically, select the **Send Report?** checkbox.

**4** Click **Apply**.

A **Results** page indicates the weekly status report information has been saved.

**5** Click **OK** to return to the **Monitoring Configuration** page.

---

## Event History Page

The **Event History** page allows you to view a list of library events.

To view the **Event History** page, click **Event History** in the Navigation frame, under **ALERT Library Management**.

The Management frame displays the **Event History** page (see [figure 16](#)).

Figure 16 Event History Page



This page lists information about events, errors, or changes in the library and its operations by:

- **Title** - the specific trap code

- **Description** - a brief description of the code, including the Fault System Code Identifier
- **Originator** - the equipment returning the information, such as the library (frame) number
- **Time Stamp** - the time and date the error or event occurred

This information can be used as a log of the general service and usage of the library.

## Chapter 5

# Fibre Channel Management

---

Fibre Channel Management allows you to remotely manage and configure one or more FC420 Fibre Channel bridges that are installed in your library (or libraries).

**Note:** Fibre Channel Management is only available when one or more FC420 bridges are installed in your library and are connected to the MC300 Prism Management Card (PMC) through a dedicated 100BaseT Ethernet connection (see [Cabling the FC420s to the PMC](#)).

Fibre Channel Management is controlled through the following Prism Management Console Web pages:

- [Route Status](#) - allows you to view and refresh the route maps related to the Fibre Channel bridges.
- [Bridge Status](#) - allows you to view the hardware and software status of the Fibre Channel bridges.
- [Bridge Administration](#) - allows you to configure the hardware and software settings for the Fibre Channel bridges, and reboot or upload new firmware to one or all FC420 bridges.

---

## Cabling the FC420s to the PMC

Fibre Channel Management requires a physical Ethernet connection between the PMC and all installed FC420 bridges. The physical connection is not provided with your library.

Use these instructions to cable the FC420 bridge (or bridges) to the PMC.

**Note:** These instructions call out specific Ethernet cables to be used with a 100 Mbit per second Ethernet hub/switch. Attach the hub/switch in a convenient location, based on cable lengths and routing. The hub/switch need not be located or mounted in the rack that contains the library (or libraries).

These Ethernet cables and Ethernet hub/switch are not supplied with your library and must be obtained separately.

### Cabling a Single FC420

To cable a single FC420 to the PMC:

- 1 Use a short Ethernet cross-over cable to connect the bottom Ethernet port on the PMC (ETH 1) to the Ethernet port on the FC420 bridge (see [figure 17](#) and [figure 18](#)).

**Note:** The 10-foot (3 meter) Ethernet cross-over cable supplied with the FC420 can be used if you are unable to obtain a short cable.



Figure 17 Cabling for  
a Single FC420 in an  
L25





Figure 18 Cabling for  
a Single FC420 in an  
L100



### Cabling Two or More FC420s

To cable two or more FC420s to the PMC:

- 1 Connect the bottom Ethernet port on the PMC (ETH 1) to an available port on a 100 Mbit per second Ethernet hub/switch using a CAT-5 Ethernet cable.

**Note:** If your Ethernet hub/switch includes an Uplink port, do not use it.

- 2 Connect the Ethernet port of each FC420 bridge to an available port on the Ethernet hub/switch using a CAT-5 Ethernet cable (see [figure 19](#), [figure 20](#), and [figure 21](#)).

The cabling procedure is complete.

Figure 19 Cabling for  
Three FC420s in an  
L100






Figure 20 Cabling for  
Two or More FC420s  
in Two or More L25s



Ethernet cables and hub/switch are not supplied,  
other standard cabling not shown for clarity

Figure 21 Cabling for  
Two or More FC420s  
in an L100



**Note:** You will need one hub/switch port for the MC300 and one hub/switch port for each FC420 bridge. If your hub/switch does not have enough ports, you can connect the uplink port of a second hub/switch to one of the standard ports on the primary hub/switch to provide more ports.

---

## Route Status

The **Route Status** page allows you to view and refresh the route maps related to the FC420 bridges. Access the **Route Status** page using the link provided in the Navigation frame. Under **Fibre Channel Management**, click **Route Status**. The Management frame displays the **Route Status** page (see [figure 22](#)).

**Note:** If a dialog box appears requesting your user name and password, enter the information and click **OK**.

At the top of the **Route Status** page is a line of text that denotes the number of FC420 bridges that are installed and connected to the PMC.


Each bridge is separated by a title that contains the bridge number. Under each bridge title is the route map that denotes the Fibre Channel paths from the host to the FC420 bridge, including port, bus, target, and Logical Unit Number (LUN).

A **Refresh** button at the bottom of the **Route Status** page allows you to update the route maps. When clicked, a pop-up message appears with the following message: Refreshing routes may affect current operations on the bridges. Do you want to continue?

Click **Cancel** to cancel the refresh request or **OK** to proceed with refreshing the route status.

**Caution:** Do not use the **Refresh** button when backup jobs are running. Wait until the library is idle.

Figure 22 Route Status



Each bridge is displayed with a table that describes the routes that have been created (see [table 10](#)).

Table 10 Route Status Descriptions

Field	Description
<b>LUN</b>	The LUN assigned to the Fibre Channel port
<b>Device</b>	The type of SCSI device that is using the LUN (the available types are <b>CHANGER</b> or <b>TAPE</b> )
<b>Bus:Target:LUN</b>	The bus, target ID, and LUN of the SCSI device
<b>Vendor</b>	The vendor ID for the SCSI device
<b>Product</b>	The product ID for the SCSI device
<b>Status</b>	Indicates whether the SCSI device is <b>Online</b> or <b>Offline</b>

---

## Bridge Status

The **Bridge Status** page allows you to view the hardware and software status of the FC420 bridges. Access the **Bridge Status** page using the link provided in the Navigation frame. Under **Fibre Channel Management**, click **Bridge Status**. The Management frame displays the **Bridge Status** page (see [figure 23](#)).

**Note:** If a dialog box appears requesting your user name and password, enter the information and click **OK**.

At the top of the **Bridge Status** page is a line of text that denotes the number of FC420 bridges that are installed and connected to the PMC.

Each bridge is separated by title that contains the bridge number. Under each bridge title is the table that lists a variety of hardware and software attributes. These attributes include hardware information, such as Loop ID, IP address, and bridge temperature; and software information such as firmware revision, connection mode, and NVRAM settings.

Figure 23 Bridge Status

**Prism Management Card**

**Fibre Channel Bridge Status**

**Bridge Status**

Number of Bridges: 3

Bridge: 0

Status: OK  
Loop ID: 255  
PRISM FC420 (FB1290L100564)  
IP Address: 10.0.0.2  
Firmware Version: 1.45, Build: 009F, Build Date: Sep 24 2002 14:45:29  
NVRAM Rev: 0, CLI Rev: 0.29, Firmware Rev: 3.00.35  
WWName: 20:00:00:10:86:10:55:34  
SCSI Busses 0, 1: LVD, LVD  
Temperature: 41 C (105 F)  
Active Configuration: Sun Microsystems (v1.0)  
Fibre Connection Mode: Point-To-Point (Auto-negotiated)  
Data Rate: 1Gb (Auto-negotiated)  
Fibre Port transferring 0 MB/sec, 0 IO/sec

Bridge: 1

Status: OK  
Loop ID: 255  
PRISM FC420 (FB1290L100567)  
IP Address: 10.0.0.1  
Firmware Version: 1.45, Build: 009F, Build Date: Sep 24 2002 14:45:29  
NVRAM Rev: 0, CLI Rev: 0.29, Firmware Rev: 3.00.35  
WWName: 20:00:00:10:86:10:55:38  
SCSI Busses 0, 1: LVD, LVD  
Temperature: 49 C (120 F)  
Active Configuration: Sun Microsystems (v1.0)  
Fibre Connection Mode: Point-To-Point (Auto-negotiated)  
Data Rate: 1Gb (Auto-negotiated)  
Fibre Port transferring 0 MB/sec, 0 IO/sec

Bridge: 2

Status: OK  
Loop ID: 255  
PRISM FC420 (FB1290L100577)  
IP Address: 10.0.0.3  
Firmware Version: 1.45, Build: 009F, Build Date: Sep 24 2002 14:45:29  
NVRAM Rev: 0, CLI Rev: 0.29, Firmware Rev: 3.00.35  
WWName: 20:00:00:10:86:10:55:70  
SCSI Busses 0, 1: LVD, LVD  
Temperature: 47 C (116 F)  
Active Configuration: Sun Microsystems (v1.0)  
Fibre Connection Mode: Point-To-Point (Auto-negotiated)  
Data Rate: 1Gb (Auto-negotiated)  
Fibre Port transferring 0 MB/sec, 0 IO/sec

[Help](#)



The hardware and software status information within the table is defined below (see [table 11](#)).

Table 11 Bridge  
Status Descriptions

<b>Field</b>	<b>Description</b>
<b>Status</b>	Displays the status of the Fibre Channel port
<b>Loop ID</b>	Displays the Loop ID entry for the Fibre Channel port
<b>PRISM FC420</b>	Displays the serial number and name of the Prism FC420 bridge, the xxx indicates the serial number of the bridge present in the library
<b>IP Address</b>	Displays the IP address for the bridge
<b>Firmware Version</b>	Displays the firmware version of the bridge
<b>NVRAM Rev, CLI Rev, Firmware Rev</b>	Displays the current revision levels for the NVRAM, Command Line Interface, and the Fibre Channel bridge firmware
<b>WWName</b>	Displays the World Wide Name (WWN) for the Fibre Channel port
<b>SCSI Busses n = LVD</b>	Displays the number and type of SCSI busses
<b>Temperature</b>	Indicates the temperature of the FC420 bridge in degrees Celsius (Fahrenheit)
<b>Active Configuration</b>	Displays the internal name of the active OEM configuration file (if one exists)
<b>Fibre Connection Mode</b>	Displays whether the Fibre Channel connection mode is Loop, Point-to-Point (PTP), Loop-PTP, or PTP-Loop
<b>Data Rate</b>	Displays the data rate of the Fibre Channel connection (1 or 2 gigabit per second)
<b>Fibre Port transferring xxx MB/sec, xxx IOs/sec</b>	Displays the transfer rate for the Fibre Channel port in MB/sec, IOs/sec

---

## Bridge Administration

The **Bridge Administration** page allows you to configure the hardware and software settings for each FC420 bridge (listed in the tables on the **Bridge Status** page). Access the **Bridge Administration** page using the link provided in the Navigation frame. Under **Fibre Channel Management**, click **Bridge Administration**. The Management frame displays the **Bridge Administration** page (see [figure 24](#)).

<p><b>Note:</b> If a dialog box appears requesting your user name and password, enter the information and click <b>OK</b>.</p>
--

The hardware and software settings for each FC420 bridge are:

- **Set Fibre Channel Data Rate** - configures the data transfer rate at which the bridge will operate. The options are 1 Gb per second, 2 Gb per second, or Auto-negotiated (takes effect after a reboot).
- **Set Fibre Channel Loop ID** - configures a hard addressing (0 - 125) or soft addressing (255) for the Loop ID during initialization (takes effect after a reboot).
- **Reboot Bridge** - allows you to reboot one or all bridges. A bridge takes approximately 30 seconds to reboot.
- **Upload New Bridge Firmware** - installs new bridge firmware to one bridge or all bridges. It takes approximately 60 seconds to upload new bridge firmware. The bridge(s) are automatically rebooted. The new firmware becomes active after the reboot.

Figure 24 Bridge Administration

The screenshot shows the Prism Management Card interface for Bridge Administration. The top header includes the Sun Microsystems logo and the text "Prism Management Card". A left-hand navigation menu lists: Prism Home, PMC Server Management, ALERT E-mail, ALERT Library Management, Fibre Channel Management (with sub-items: Route Status, Bridge Status, Bridge Administration), and Help. The main content area is titled "Fibre Channel Bridge Administration" and contains four sections:

- Set Fibre Channel Data Rate:** Includes a "Bridge:" dropdown menu set to "0" and a "Mode:" dropdown menu set to "Auto". Below are "Apply" and "Help" buttons. A note states: "Note: The new Data Rate will not take effect until the bridge is rebooted."
- Set Fibre Channel Loop ID:** Includes a "Bridge:" dropdown menu set to "0" and an empty "Loop ID:" text input field. Below are "Apply" and "Help" buttons. A note states: "Note: The new Loop ID will not take effect until the bridge is rebooted."
- Reboot Bridge:** Includes a "Bridge:" dropdown menu set to "0". Below are "OK" and "Help" buttons. A note states: "Note: It will take the bridge approximately 30 seconds to reboot."
- Upload New Bridge Firmware:** Includes a "Bridge:" dropdown menu set to "0" and a "Firmware Image:" text input field with a "Browse..." button. Below are "Upload" and "Help" buttons. A note states: "Note: It will take approximately 60 seconds to upload a new bridge firmware. The new firmware will take effect immediately (bridge is automatically rebooted)."

---

### Setting the Fibre Channel Data Rate

To configure the Fibre Channel data rate:

- 1 Access the **Bridge Administration** page.  
In the Navigation frame, under **Fibre Channel Management**, click **Bridge Administration**.
- 2 Under **Set Fibre Channel Data Rate**, select a bridge from the **Bridge** pull-down list.
- 3 Select a data rate from the **Data Rate** pull-down list.

The data rate types include:

- **Auto Negotiate**
- **1 Gb**
- **2 Gb**

- 4 Click **Apply**.

A **Results** page displays indicating the data rate was configured.

**Note:** Reboot the FC420 bridge to utilize the new connection mode (see [Rebooting a Bridge](#)).

---

### Setting the Fibre Channel Loop ID

To configure the Fibre Channel loop ID:

- 1 Access the **Bridge Administration** page.  
In the Navigation frame, under **Fibre Channel Management**, click **Bridge Administration**.
- 2 Under **Set Fibre Channel Loop ID**, select a bridge from the **Bridge** pull-down list.
- 3 Enter the desired **Loop ID** for the selected bridge.

**Note:** Enter a number between 0 - 125 for hard addressing to the Fibre port. To disable hard addressing and use soft addressing to the Fibre port, enter 255.

**4 Click Apply.**

A **Results** page appears indicating the loop ID was configured.

**Note:** Reboot the FC420 bridge to utilize the new connection mode.

---

### Rebooting a Bridge

To reboot one or all bridges:

**1** Access the **Bridge Administration** page.

In the Navigation frame, under **Fibre Channel Management**, click **Bridge Administration**.

**2** Select a specific bridge or **All** from the **Bridge** pull-down list.

**3** Click **OK**.

**Note:** The bridge takes approximately 30 seconds to reboot.

---

### Uploading Bridge Firmware

To upload bridge firmware:

**1** Access the **Bridge Administration** page.

In the Navigation frame, under **Fibre Channel Management**, click **Bridge Administration**.

**2** Select a specific bridge or **All** from the **Bridge** pull-down list.

**3** Enter the name of the firmware image file or click the Browse button to select the firmware image file.

**4** Click **OK**.

A **Results** page displays indicating the file was uploaded successfully.



## Chapter 6

# Getting Help


---

The Prism Management Console Web pages provide extensive online help files, which define actions and terms for all functions, features, and fields.

To access the **Help** pages:

- Click the **Help** link at the bottom of the Navigation frame.  
A new Internet browser window opens and displays the first page of the online help files.
- Click the **Help** button at the bottom of the current Web page.  
A new Internet browser window opens and displays online help for the current Web page. [Figure 25](#) shows the Help page for the Prism Management Console Home page.

Figure 25 Home Page Help





## Appendix A

# Event Details Listing

---

Table 12 Information  
Events Detail

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
2403	No mail generated	Source is empty.
2404	No mail generated	Destination is full.
2405	No mail generated	Element address supplied is invalid.
2408	No mail generated	Destination slot not present. Magazine or drive removed.
2413	No mail generated	Source slot not present. Magazine or drive removed.
2415	No mail generated	Move medium attempted to drive that is being auto cleaned.
2418	Soft error	Requested action cannot be performed because robot is busy or in use.
2629	Hardware failure	A hand jam has been recovered.
2A00	Soft error	Shuttle queue is full.
4000	Soft error	SCSI command received for invalid LUN.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
4001	Soft error	An ASC/ ASCQ was used without updating error log logging.
4002	Soft error	Illegal SCSI command received.
4003	Soft error	Command received but library is busy.
4004	Soft error	Deferred error is pending.
4005	Soft error	Unit attention - due to reset.
4006	Soft error	Unit attention - due to mode parameters changed.
4007	Soft error	Unit attention - due to medium changed.
4008	Soft error	SCSI command had invalid field in CDB.
4009	Soft error	SCSI command had parameter list length error.
400A	Soft error	SCSI command had invalid field in parameter list.
400B	Soft error	SCSI command had invalid parameter value.
400C	Soft error	SCSI command failed due to servo problem.
400D	Soft error	No sense available.
400E	Soft error	Cleaner cartridge present.
400F	No mail generated	Move medium destination full.
4010	No mail generated	Move medium source empty.
4011	Soft error	Parameters not saved. Undefined.
4012	Soft error	Illegal element number.
4013	Soft error	Cannot complete command while cartridge is in hand.
4014	Soft error	Power-on configuration not yet finished.
4015	Soft error	Library will be ready soon, check back later.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
4016	Soft error	Not ready - unknown reason.
4017	Operator access	Door is open.
4018	Operator access	Import/export is open.
4019	Configuration change	Operator panel is in menu mode.
401A	Operator access	Import/export has been accessed.
401B	Operator access	Command failed due to reservation conflict.
401C	Operator access	SCSI bus reset received.
401D	Operator access	SCSI bus device reset message received.
401E	Operator access	SCSI abort message received.
401F	Operator access	SCSI parity error received.
4020	Operator access	SCSI initiator detected error received.
4100	Configuration change	Time was set via serial port.
4101	Configuration change	Time set via synchronization command.
4102	Configuration change	Synchronize clock command issued.
4103	No mail generated	Library is rebooting.
4104	Configuration change	Library entering boot mode.
4105	No mail generated	Library has just started.
4106	Soft error	Time-out waiting for remote ACK.
4107	Soft error	Time-out waiting for remote response.
4108	Soft error	Remote machine sent time-out message.
4400	Operator access	Robot paused for operator safety (robotics accessible by operator).

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
4401	Operator access	Door 1 open (left door).
4402	Operator access	Door 2 open (right door).
4403	Operator access	Door 3 open.
4404	Operator access	Door 4 open.
4405	Operator access	Door 1 closed (left door).
4406	Operator access	Door 2 closed (right door).
4407	Operator access	Door 3 closed.
4408	Operator access	Door 4 closed.
4409	No mail generated	Magazine 1 has been removed (left magazine).
440A	No mail generated	Magazine 2 has been removed (right magazine).
440B	No mail generated	Magazine 3 has been removed (left magazine).
440C	No mail generated	Magazine 4 has been removed (right magazine).
440D	No mail generated	Magazine 5 has been removed (left magazine).
440E	No mail generated	Magazine 6 has been removed (right magazine).
440F	No mail generated	Magazine 7 has been removed (left magazine).
4410	No mail generated	Magazine 8 has been removed (right magazine).
4411	No mail generated	Magazine 9 has been removed (left magazine).
4412	No mail generated	Magazine 10 has been removed (right magazine).
4413	No mail generated	Magazine 1 has been inserted (left magazine).
4414	No mail generated	Magazine 2 has been inserted (right magazine).
4415	No mail generated	Magazine 3 has been inserted (left magazine).
4416	No mail generated	Magazine 4 has been inserted (right magazine).

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
4417	No mail generated	Magazine 5 has been inserted (left magazine).
4418	No mail generated	Magazine 6 has been inserted (right magazine).
4419	No mail generated	Magazine 7 has been inserted (left magazine).
441A	No mail generated	Magazine 8 has been inserted (right magazine).
441B	No mail generated	Magazine 9 has been inserted (left magazine).
441C	No mail generated	Magazine 10 has been inserted (right magazine).
441D	No mail generated	Magazine 1 absent at power-up (left magazine).
441E	No mail generated	Magazine 2 absent at power-up (right magazine).
441F	No mail generated	Magazine 3 absent at power-up (left magazine).
4420	No mail generated	Magazine 4 absent at power-up (right magazine).
4421	No mail generated	Magazine 5 absent at power-up (left magazine).
4422	No mail generated	Magazine 6 absent at power-up (right magazine).
4423	No mail generated	Magazine 7 absent at power-up (left magazine).
4424	No mail generated	Magazine 8 absent at power-up (right magazine).
4425	No mail generated	Magazine 9 absent at power-up (left magazine).
4426	No mail generated	Magazine 10 absent at power-up (right magazine).
4427	No mail generated	Library ready.
4428	No mail generated	Library not ready.
4429	No mail generated	Drive 1 in this library module removed.
442A	No mail generated	Drive 2 in this library module removed.
442B	No mail generated	Drive 3 in this library module removed.
442C	No mail generated	Drive 4 in this library module removed.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
442D	No mail generated	Drive 5 in this library module removed.
442E	No mail generated	Drive 6 in this library module removed.
4434	No mail generated	Drive 1 in this library module inserted.
4435	No mail generated	Drive 2 in this library module inserted.
4436	No mail generated	Drive 3 in this library module inserted.
4437	No mail generated	Drive 4 in this library module inserted.
4438	No mail generated	Drive 5 in this library module inserted.
4439	No mail generated	Drive 6 in this library module inserted.
443E	No mail generated	Drive 1 in this library module absent at power-on.
443F	No mail generated	Drive 2 in this library module absent at power-on.
4440	No mail generated	Drive 3 in this library module absent at power-on.
4441	No mail generated	Drive 4 in this library module absent at power-on.
4442	No mail generated	Drive 5 in this library module absent at power-on.
4443	No mail generated	Drive 6 in this library module absent at power-on.
4448	No mail generated	Drive 1 in this library module has powered up.
4449	No mail generated	Drive 2 in this library module has powered up.
444A	No mail generated	Drive 3 in this library module has powered up.
444B	No mail generated	Drive 4 in this library module has powered up.
444C	No mail generated	Drive 5 in this library module has powered up.
444D	No mail generated	Drive 6 in this library module has powered up.
4452	No mail generated	Drive 1 in this library module has powered down.
4453	No mail generated	Drive 2 in this library module has powered down.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
4454	No mail generated	Drive 3 in this library module has powered down.
4455	No mail generated	Drive 4 in this library module has powered down.
4456	No mail generated	Drive 5 in this library module has powered down.
4457	No mail generated	Drive 6 in this library module has powered down.
445C	Soft error	Drive 1 in this library module requesting auto clean.
445D	Soft error	Drive 2 in this library module requesting auto clean.
445E	Soft error	Drive 3 in this library module requesting auto clean.
445F	Soft error	Drive 4 in this library module requesting auto clean.
4460	Soft error	Drive 5 in this library module requesting auto clean.
4461	Soft error	Drive 6 in this library module requesting auto clean.
4466	Soft error	Cleaning cycle started on Drive 1 in this library module.
4467	Soft error	Cleaning cycle started on Drive 2 in this library module.
4468	Soft error	Cleaning cycle started on Drive 3 in this library module.
4469	Soft error	Cleaning cycle started on Drive 4 in this library module.
446A	Soft error	Cleaning cycle started on Drive 5 in this library module.
446B	Soft error	Cleaning cycle started on Drive 6 in this library module.
4470	Soft error	Cleaning tape expired.
4471	Soft error	Drive clean attempted with a noncleaning tape.
4472	Soft error	Drive 1 in this library module has been cleaned successfully.
4473	Soft error	Drive 2 in this library module has been cleaned successfully.
4474	Soft error	Drive 3 in this library module has been cleaned successfully.
4475	Soft error	Drive 4 in this library module has been cleaned successfully.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
4476	Soft error	Drive 5 in this library module has been cleaned successfully.
4477	Soft error	Drive 6 in this library module has been cleaned successfully.
447C	Soft error	Drive 1 in this library module is still requesting cleaning after being cleaned.
447D	Soft error	Drive 2 in this library module is still requesting cleaning after being cleaned.
447E	Soft error	Drive 3 in this library module is still requesting cleaning after being cleaned.
447F	Soft error	Drive 4 in this library module is still requesting cleaning after being cleaned.
4480	Soft error	Drive 5 in this library module is still requesting cleaning after being cleaned.
4481	Soft error	Drive 6 in this library module is still requesting cleaning after being cleaned.
4486	No mail generated	Module at level 1 in stack has been powered down/disconnected.
4487	No mail generated	Module at level 2 in stack has been powered down/disconnected.
4488	No mail generated	Module at level 3 in stack has been powered down/disconnected.
4489	No mail generated	Module at level 4 in stack has been powered down/disconnected.
448A	No mail generated	Module at level 5 in stack has been powered down/disconnected.
448B	No mail generated	Module at level 6 in stack has been powered down/disconnected.



<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
448C	No mail generated	Module at level 7 in stack has been powered down/disconnected.
448D	No mail generated	Module at level 8 in stack has been powered down/disconnected.
448E	No mail generated	Module at level 9 in stack has been powered down/disconnected.
448F	No mail generated	Module at level 10 in stack has been powered down/disconnected.
4490	No mail generated	Module at level 11 in stack has been powered down/disconnected.
4491	No mail generated	Module at level 12 in stack has been powered down/disconnected.
4492	No mail generated	New module has joined stack.
4493	No mail generated	Level 1 installed in stack.
4494	No mail generated	Level 2 installed in stack.
4495	No mail generated	Level 3 installed in stack.
4496	No mail generated	Level 4 installed in stack.
4497	No mail generated	Level 5 installed in stack.
4498	No mail generated	Level 6 installed in stack.
4499	No mail generated	Level 7 installed in stack.
449A	No mail generated	Level 8 installed in stack.
449B	No mail generated	Level 9 installed in stack.
449C	No mail generated	Level 10 installed in stack.
449D	No mail generated	Level 11 installed in stack.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
449E	No mail generated	Level 12 installed in stack.
449F	No mail generated	Level 1 not installed in stack.
44A0	No mail generated	Level 2 not installed in stack.
44A1	No mail generated	Level 3 not installed in stack.
44A2	No mail generated	Level 4 not installed in stack.
44A3	No mail generated	Level 5 not installed in stack.
44A4	No mail generated	Level 6 not installed in stack.
44A5	No mail generated	Level 7 not installed in stack.
44A6	No mail generated	Level 8 not installed in stack.
44A7	No mail generated	Level 9 not installed in stack.
44A8	No mail generated	Level 10 not installed in stack.
44A9	No mail generated	Level 11 not installed in stack.
44AA	No mail generated	Level 12 not installed in stack.
4600	No mail generated	The library's power-on initialization sequence has completed.
4680	Soft error	Drive 1 in this library module has rejected the cartridge. A reload is underway.
4681	Soft error	Drive 2 in this library module has rejected the cartridge. A reload is underway.
4682	Soft error	Drive 3 in this library module has rejected the cartridge. A reload is underway.
4683	Soft error	Drive 4 in this library module has rejected the cartridge. A reload is underway.
4684	Soft error	Drive 5 in this library module has rejected the cartridge. A reload is underway.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
4685	Soft error	Drive 6 in this library module has rejected the cartridge. A reload is underway.
4900	Configuration change	This unit has become the stack-master (elevator controller).
4901	Configuration change	This unit has changed from stack-master to slave module.
4902	Soft error	The stack-master is no longer polling this unit.

<b>Tape Alert Flag</b>	<b>E-mail Message Type</b>	<b>Description</b>
10	Soft error	Manual or software unload attempted while prevent media removal on.
11	Soft error	Cleaning tape encountered during backup or restore.
12	Soft error	Attempted load of unsupported tape format.
17	Soft error	Media loaded that is read-only format.
19	Soft error	The tape cartridge is nearing the end of its calculated life.

Table 13 Warning  
Events Detail

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
000A	Hardware failure	Hand CV check found hand disconnected.
000B	Hardware failure	Servo CV check found servo board disconnected.
000C	Hardware failure	X axis CV check found X axis disconnected.
000D	Hardware failure	Y axis CV check found Y axis disconnected.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
000E	Hardware failure	Z axis CV check found Z axis disconnected.
000F	Hardware failure	FP CV check found front panel disconnected.
0020	Soft error	OS timer interrupt has not occurred, but should have.
200A	Hardware failure	Drive caddy not present (drive 1 in this library module).
200B	Hardware failure	Drive caddy not present (drive 2 in this library module).
200C	Hardware failure	Drive caddy not present (drive 3 in this library module).
200D	Hardware failure	Drive caddy not present (drive 4 in this library module).
200E	Hardware failure	Drive caddy not present (drive 5 in this library module).
200F	Hardware failure	Drive caddy not present (drive 6 in this library module).
2022	Hardware failure	The requested function is not implemented in the drive type.
202C	Hardware failure	Response packet received from drive 1 in this library module indicates command failed.
202D	Hardware failure	Response packet received from drive 2 in this library module indicates command failed.
202E	Hardware failure	Response packet received from drive 3 in this library module indicates command failed.
202F	Hardware failure	Response packet received from drive 4 in this library module indicates command failed.
2030	Hardware failure	Response packet received from drive 5 in this library module indicates command failed.
2031	Hardware failure	Response packet received from drive 6 in this library module indicates command failed.
2034	Hardware failure	Response received from drive 1 in this library module indicates drive busy.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
2035	Hardware failure	Response received from drive 2 in this library module indicates drive busy.
2036	Hardware failure	Response received from drive 3 in this library module indicates drive busy.
2037	Hardware failure	Response received from drive 4 in this library module indicates drive busy.
2038	Hardware failure	Response received from drive 5 in this library module indicates drive busy.
2039	Hardware failure	Response received from drive 6 in this library module indicates drive busy.
2104	Hardware failure	Expected response from hardware was not received.
2303	Hardware failure	Barcode reader did not find a barcode.
2409	Hardware failure	Magazine removed when door was shut.
240A	Hardware failure	Magazine inserted without proper access.
240B	Soft error	Demo stopped; no slot available for cartridge destination.
240C	Soft error	Sequence stopped; no cartridge available to perform requested action.
240D	Soft error	Librarian uncertain of cartridge origin.
240E	Hardware failure	Manual intervention required to remove cartridge from the elevator.
240F	Hardware failure	The requested move cannot be performed.
2410	Hardware failure	The requested move cannot be performed.
2411	Hardware failure	Auto clean cannot be performed as there are no cleaning tapes.
2412	Hardware failure	Auto clean cannot be performed as all the cleaning tapes are in use.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
2414	Soft error	Demo unable to select random start slot. Try rerunning demo.
2417	Soft error	Fixed slot reserved for dedicated cleaner; not for general use.
2419	Soft error	Illegal magazine configuration. Recheck.
241A	Soft error	Stack contains modules configured for different media to stack-master.
241B	Soft error	Fixed slot detected when library configured for 6 drive operation.
241C	Soft error	No fixed slot detected when library configured for 5 drive operation.
241D	Soft error	Magazine 5 detected when library configured for 6 drive operation.
241E	Soft error	Drive 3 in this library module detected when library configured for 5 drive operation.
2504	Soft error	Bad page code in send diagnostic.
2612	Soft error	Requested action cannot be carried out with a cartridge in the hand.
2613	Soft error	Requested action cannot be carried out without a cartridge in the hand.
261A	Hardware failure	The hand action 'completed' with no cartridge detected in the source.
2624	Hardware failure	The (nvr spec'd) xy build does not provide access to the cleaner slot.
2625	Hardware failure	The elevator vertical position is still unknown.
2634	Hardware failure	The inserted magazine has not been pushed fully home.
2636	Hardware failure	The elevator X axis offset is too great; likely build error.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
2637	Hardware failure	The elevator is set too far back on the hand axis; likely build error.
263B	Soft error	The cleaning tape in use has expired.
263C	Soft error	The auto clean cycle has loaded a noncleaning or invalid tape.
263E	Hardware failure	The cartridge is not fully in the elevator; manual intervention required.
263F	Hardware failure	Manual intervention and power cycle are required.
2640	Hardware failure	Detail is not known, but manual intervention and power cycle required.
2641	Hardware failure	The fixed slot check has detected a fixed slot.
26B8	Soft error	Drive 1 in this library module has no cartridge to unload.
26B9	Soft error	Drive 2 in this library module has no cartridge to unload.
26BA	Soft error	Drive 3 in this library module has no cartridge to unload.
26BB	Soft error	Drive 4 in this library module has no cartridge to unload.
26BC	Soft error	Drive 5 in this library module has no cartridge to unload.
26BD	Soft error	Drive 6 in this library module has no cartridge to unload.
26D8	Hardware failure	Attempt to initialize Drive 1 in this library module before it has become available.
26D9	Hardware failure	Attempt to initialize Drive 2 in this library module before it has become available.
26DA	Hardware failure	Attempt to initialize Drive 3 in this library module before it has become available.
26DB	Hardware failure	Attempt to initialize Drive 4 in this library module before it has become available.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
26DC	Hardware failure	Attempt to initialize Drive 5 in this library module before it has become available.
26DD	Hardware failure	Attempt to initialize Drive 6 in this library module before it has become available.
4200	Soft error	NVR CRC invalid and contents probably corrupt.

<b>Tape Alert Flag</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
1	Soft error	The drive is having severe trouble reading the media.
2	Soft error	The drive is having severe trouble reading the media.
3	Hardware failure	The drive had a hard read or write error.
7	Soft error	The media has exceeded its specified life.
8	Soft error	The drive has not been able to read the MRS stripes.
15	Soft error	Memory chip failed in cartridge.
16	Soft error	Manual or forced eject while drive actively writing or reading.
18	Soft error	Directory data stored on tape has been corrupted.
21	Soft error	The drive is ready for a periodic cleaning.
23	Soft error	Invalid cleaning tape type used.
29	Soft error	The drive requires preventive maintenance other than cleaning.
32	Hardware failure	The drive has identified an interfacing fault.
34	Soft error	Firmware download failed.



<b>Tape Alert Flag</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
35	Soft error	Drive humidity limits exceeded.
36	Soft error	Drive temperature limits exceeded.
37	Soft error	Drive voltage limits exceeded.
38	Soft error	Predictive failure of drive hardware.
39	Soft error	The drive may have a hardware fault that extended diagnostics may help identify.
42	Hardware failure	Library mechanism has a hardware fault.
46	Soft error	Predictive failure of loader mechanism hardware.
65	Soft error	Unknown tape alert flag.
69	Soft error	Unknown tape alert flag.

Table 14 Failure Events Detail

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
0001	Hardware failure	A divide by zero exception has occurred.
0002	Hardware failure	A parity error has been detected on the address/data bus.
0003	Hardware failure	Out of memory.
0004	Soft error	_flsbuf was called.
0005	Soft error	_getbuf was called.
0006	Hardware failure	Stack was exhausted.
0007	Hardware failure	Floating point trap.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
0008	Hardware failure	Free() called on bad memory block.
0009	Hardware failure	Realloc() found corrupted memory block.
0010	Hardware failure	Free() found corrupted memory block trailer.
0011	Hardware failure	Realloc() found corrupted memory block trailer.
0012	Hardware failure	NVR capacity exceeded.
0013	Hardware failure	Heap consistency check found corruption.
0014	Hardware failure	Heap consistency check found corruption.
0015	Hardware failure	Watchdog has interrupted processor.
0016	Hardware failure	Size passed to malloc too large.
0017	Hardware failure	Size passed to calloc too large.
0018	Hardware failure	Size passed to realloc too large.
0019	Hardware failure	Breakpoint instruction executed.
001A	Hardware failure	Debug exception occurred.
001B	Hardware failure	Code attempted to write to address 0.
001C	Hardware failure	Code attempted to execute at address 0.
001D	Hardware failure	Code attempted to write to address 0.
001E	Hardware failure	Code attempted to execute at address 0.
001F	Hardware failure	Old system boards are no longer supported.
1000	Hardware failure	FPGA INIT pin was detected as being high when it should have been low.
1001	Hardware failure	FPGA INIT pin was detected as being low when it should have been high.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
1002	Hardware failure	FPGA DONE pin was detected as being high when it should have been low.
1003	Hardware failure	FPGA DONE pin was detected as being low when it should have been high.
2000	Hardware failure	DLT initialization failed.
2001	Hardware failure	Drive time-out waiting for status (drive 1 in this library module).
2002	Hardware failure	Drive time-out waiting for status (drive 2 in this library module).
2003	Hardware failure	Drive time-out waiting for status (drive 3 in this library module).
2004	Hardware failure	Drive time-out waiting for status (drive 4 in this library module).
2005	Hardware failure	Drive time-out waiting for status (drive 5 in this library module).
2006	Hardware failure	Drive time-out waiting for status (drive 6 in this library module).
2009	Hardware failure	Requires newer version of system board.
2012	Hardware failure	Invalid byte received from drive 1 in this library module.
2013	Hardware failure	Invalid byte received from drive 2 in this library module.
2014	Hardware failure	Invalid byte received from drive 3 in this library module.
2015	Hardware failure	Invalid byte received from drive 4 in this library module.
2016	Hardware failure	Invalid byte received from drive 5 in this library module.
2017	Hardware failure	Invalid byte received from drive 6 in this library module.
201A	Soft error	Invalid packet received from drive 1 in this library module.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
201B	Soft error	Invalid packet received from drive 2 in this library module.
201C	Soft error	Invalid packet received from drive 3 in this library module.
201D	Soft error	Invalid packet received from drive 4 in this library module.
201E	Soft error	Invalid packet received from drive 5 in this library module.
201F	Soft error	Invalid packet received from drive 6 in this library module.
2023	Hardware failure	Could not get a semaphore from OS.
2024	Hardware failure	Response packet received from drive 1 in this library module indicates command failed.
2025	Hardware failure	Response packet received from drive 2 in this library module indicates command failed.
2026	Hardware failure	Response packet received from drive 3 in this library module indicates command failed.
2027	Hardware failure	Response packet received from drive 4 in this library module indicates command failed.
2028	Hardware failure	Response packet received from drive 5 in this library module indicates command failed.
2029	Hardware failure	Response packet received from drive 6 in this library module indicates command failed.
2100	Hardware failure	I2C interface failed to initialize.
2101	Hardware failure	Timed out waiting for I2C bus to go not busy.
2102	Hardware failure	No acknowledge received from slave.
2103	Hardware failure	Exceeded retry limit while trying to send message.
2105	Hardware failure	Message received from I2C bus but destination is unknown.
2106	Hardware failure	Message to send over I2C bus is too large (see path).

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
2107	Hardware failure	Message received over I2C bus is too large.
2108	Hardware failure	I2C mailbox is full.
2109	Hardware failure	Receiver address in I2C message incorrect.
210A	Hardware failure	Pending interrupt status not reset.
2200	Hardware failure	UI task initialization failed.
2201	Hardware failure	UI queue full.
2202	Hardware failure	The UI is not in the correct state to perform the requested action.
2301	Hardware failure	Timed out waiting for data from barcode reader.
2302	Hardware failure	Did not detect barcode reader.
2400	Hardware failure	Librarian task initialization failed.
2401	Hardware failure	Librarian task received an unknown or unexpected message.
2402	Hardware failure	Librarian queue full.
2406	Hardware failure	Servo initialization not complete. Librarian unsure of servo status.
2407	Hardware failure	Servo turned off due to failure. Librarian unsure of servo status.
2416	Hardware failure	Bad parameter in Librarian message.
2500	Hardware failure	SCSI task initialization failed.
2501	Soft error	SCSI task received a bad message.
2502	Hardware failure	SCSI queue full.
2503	Hardware failure	FAS366 not detected.
2600	Hardware failure	Servo task initialization failed.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
2601	Hardware failure	Servo queue full.
2602	Hardware failure	The X axis failed to get to its target position.
2603	Hardware failure	The Y axis failed to get to its target position.
2604	Hardware failure	The Theta axis failed to get to its target position.
2605	Hardware failure	The hand axis failed to get to its target position.
2606	Hardware failure	The elevator axis failed to get to its target position.
2607	Hardware failure	The Z axis failed to get to its target location.
2608	Hardware failure	The X axis tachometer failed to clear at power-on.
2609	Hardware failure	The Y axis tachometer failed to clear at power-on.
260A	Hardware failure	The Theta axis tachometer failed to clear at power-on.
260B	Hardware failure	The hand axis tachometer failed to clear at power-on.
260C	Hardware failure	The elevator axis tachometer failed to clear at power-on.
260D	Hardware failure	The Z axis tachometer failed to clear at power-on.
260E	Hardware failure	The hand could not be returned to the XY center during power-on.
260F	Hardware failure	The servo task has received an invalid command code.
2610	Hardware failure	The hand action 'completed' with no cartridge detected in the hand.
2611	Soft error	The put action 'completed' with the cartridge still in the hand.
2614	Soft error	Command cannot be executed without first initializing the axis.
2615	Hardware failure	Theta nvr data has been corrupted, or not yet initialized.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
2616	Hardware failure	Axis friction nvr data has been corrupted, or not yet initialized.
2617	Hardware failure	Axis offset nvr data has been corrupted.
2618	Hardware failure	The build nvr data has been corrupted, or not initialized.
2619	Hardware failure	An error has been detected in the servo nvr.
261B	Hardware failure	The hand action 'completed' but there was a hand sensor failure.
261C	Hardware failure	The hand action 'completed' but was unable to engage.
261D	Hardware failure	The hand will not move in either direction.
261E	Hardware failure	The hand could not get the cartridge to its required position.
261F	Hardware failure	The elevator sensor of the box was not detected during elevator calibration.
2620	Hardware failure	Elevator nvr data has been corrupted or not yet initialized.
2621	Hardware failure	The X axis cannot be moved properly in either direction.
2622	Hardware failure	The servo failed to raise the drive hub.
2623	Hardware failure	The cartridge is still being retained by the drive.
2626	Hardware failure	The Theta angles are out of specification after calibration attempt.
2627	Hardware failure	The X axis did not travel the minimum distance when calibrating.
2628	Hardware failure	The Y axis did not travel the minimum distance when calibrating.
262A	Hardware failure	The Theta sensor closest to the right magazine failed to switch.
262B	Hardware failure	The Theta sensor closest to the left magazine failed to switch.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
262C	Hardware failure	The X axis sensor could not be detected changing state.
262D	Hardware failure	The Y axis sensor could not be detected changing state.
262E	Hardware failure	The hand axis did not travel the minimum distance when calibrating.
262F	Hardware failure	The X axis friction is too high for normal operation.
2630	Hardware failure	The Y axis friction is too high for normal operation.
2631	Hardware failure	The Theta axis friction is too high for normal operation.
2632	Hardware failure	The hand axis friction is too high for normal operation.
2633	Hardware failure	The Z axis did not travel the minimum distance when calibrating.
2635	Hardware failure	The Z axis friction is too high for normal operation.
2638	Hardware failure	One of the axis has suffered a gross position error.
2639	Hardware failure	The cartridge position error detected on the Y axis is too great.
263A	Hardware failure	The cartridge position error detected on the X axis is too great.
263D	Hardware failure	The elevator has not been detected opposite the hand during calibration.
2680	Hardware failure	Drive 1 in this library module has reported a hardware error.
2681	Hardware failure	Drive 2 in this library module has reported a hardware error.
2682	Hardware failure	Drive 3 in this library module has reported a hardware error.
2683	Hardware failure	Drive 4 in this library module has reported a hardware error.
2684	Hardware failure	Drive 5 in this library module has reported a hardware error.
2685	Hardware failure	Drive 6 in this library module has reported a hardware error.



<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
2688	Hardware failure	Drive 1 in this library module will not allow the hand to be operated as required.
2689	Hardware failure	Drive 2 in this library module will not allow the hand to be operated as required.
268A	Hardware failure	Drive 3 in this library module will not allow the hand to be operated as required.
268B	Hardware failure	Drive 4 in this library module will not allow the hand to be operated as required.
268C	Hardware failure	Drive 5 in this library module will not allow the hand to be operated as required.
268D	Hardware failure	Drive 6 in this library module will not allow the hand to be operated as required.
2690	Hardware failure	Drive 1 in this library module hand failed to close.
2691	Hardware failure	Drive 2 in this library module hand failed to close.
2692	Hardware failure	Drive 3 in this library module hand failed to close.
2693	Hardware failure	Drive 4 in this library module hand failed to close.
2694	Hardware failure	Drive 5 in this library module hand failed to close.
2695	Hardware failure	Drive 6 in this library module hand failed to close.
2698	Hardware failure	Drive 1 in this library module hand failed to open.
2699	Hardware failure	Drive 2 in this library module hand failed to open.
269A	Hardware failure	Drive 3 in this library module hand failed to open.
269B	Hardware failure	Drive 4 in this library module hand failed to open.
269C	Hardware failure	Drive 5 in this library module hand failed to open.
269D	Hardware failure	Drive 6 in this library module hand failed to open.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
26A0	Hardware failure	Drive 1 in this library module is indicating 'in flux,' not ready for commands.
26A1	Hardware failure	Drive 2 in this library module is indicating 'in flux,' not ready for commands.
26A2	Hardware failure	Drive 3 in this library module is indicating 'in flux,' not ready for commands.
26A3	Hardware failure	Drive 4 in this library module is indicating 'in flux,' not ready for commands.
26A4	Hardware failure	Drive 5 in this library module is indicating 'in flux,' not ready for commands.
26A5	Hardware failure	Drive 6 in this library module is indicating 'in flux,' not ready for commands.
26A8	Hardware failure	Drive 1 in this library module is indicating its hand is closed and should be open.
26A9	Hardware failure	Drive 2 in this library module is indicating its hand is closed and should be open.
26AA	Hardware failure	Drive 3 in this library module is indicating its hand is closed and should be open.
26AB	Hardware failure	Drive 4 in this library module is indicating its hand is closed and should be open.
26AC	Hardware failure	Drive 5 in this library module is indicating its hand is closed and should be open.
26AD	Hardware failure	Drive 6 in this library module is indicating its hand is closed and should be open.
26B0	Hardware failure	Drive 1 in this library module is indicating its hand is open and should have been closed.
26B1	Hardware failure	Drive 2 in this library module is indicating its hand is open and should have been closed.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
26B2	Hardware failure	Drive 3 in this library module is indicating its hand is open and should have been closed.
26B3	Hardware failure	Drive 4 in this library module is indicating its hand is open and should have been closed.
26B4	Hardware failure	Drive 5 in this library module is indicating its hand is open and should have been closed.
26B5	Hardware failure	Drive 6 in this library module is indicating its hand is open and should have been closed.
26C0	Hardware failure	Drive 1 in this library module has not responded to multiple requests to unload.
26C1	Hardware failure	Drive 2 in this library module has not responded to multiple requests to unload.
26C2	Hardware failure	Drive 3 in this library module has not responded to multiple requests to unload.
26C3	Hardware failure	Drive 4 in this library module has not responded to multiple requests to unload.
26C4	Hardware failure	Drive 5 in this library module has not responded to multiple requests to unload.
26C5	Hardware failure	Drive 6 in this library module has not responded to multiple requests to unload.
26C8	Hardware failure	Drive 1 in this library module has rejected the cartridge; cannot be loaded.
26C9	Hardware failure	Drive 2 in this library module has rejected the cartridge; cannot be loaded.
26CA	Hardware failure	Drive 3 in this library module has rejected the cartridge; cannot be loaded.
26CB	Hardware failure	Drive 4 in this library module has rejected the cartridge; cannot be loaded.

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
26CC	Hardware failure	Drive 5 in this library module has rejected the cartridge; cannot be loaded.
26CD	Hardware failure	Drive 6 in this library module has rejected the cartridge; cannot be loaded.
26D0	Hardware failure	Drive 1 in this library module has failed to load the tape successfully.
26D1	Hardware failure	Drive 2 in this library module has failed to load the tape successfully.
26D2	Hardware failure	Drive 3 in this library module has failed to load the tape successfully.
26D3	Hardware failure	Drive 4 in this library module has failed to load the tape successfully.
26D4	Hardware failure	Drive 5 in this library module has failed to load the tape successfully.
26D5	Hardware failure	Drive 6 in this library module has failed to load the tape successfully.
2700	Hardware failure	PCDIAG task initialization failed.
2701	Soft error	Unknown or bad diagnostic message.
2702	Soft error	Current diagnostic stack has terminated.
2703	Soft error	PCDIAG queue full.
2704	Soft error	Diagnostic command failure; initiator task unknown.
2800	Soft error	Event Log task initialization failed.
2801	Soft error	NVR space allocated to event log is too small. See path for required space and change in system.h.
2802	Soft error	Event logger received bad retry level definition.
2803	Soft error	Number in event log is bad (log corrupted?).

<b>FSC Code</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
2900	Hardware failure	Stack Controller task initialization failed.
2901	Hardware failure	Stack Controller queue is full.
2902	Hardware failure	Stack Controller task received an unknown or unexpected message.

<b>Tape Alert Flag</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
4	Soft error	Media can no longer be written or read, or performance is severely degraded.
5	Hardware failure	The drive can no longer read data from the tape.
6	Hardware failure	The drive can no longer write data to the tape.
9	Hardware failure	Write command attempted to a write-protected tape.
13	Hardware failure	Tape snapped or cut in the drive where media can be ejected.
14	Hardware failure	Tape snapped or cut in the drive where media cannot be ejected.
20	Soft error	The drive has a head clog or needs cleaning.
22	Soft error	The cleaning tape has expired.
30	Hardware failure	The drive has a hardware fault that requires a reset to recover.
31	Hardware failure	The drive has a hardware fault that requires a power cycle to continue.
33	Soft error	Error recovery action.
40	Hardware failure	Library mechanism is having trouble communicating with the tape drive.

<b>Tape Alert Flag</b>	<b>E-mail Message Error Type</b>	<b>Description</b>
41	Soft error	Stray tape left in library after previous error recovery.
43	Operator access	Library door open.
44	Hardware failure	The library mechanism had a hardware fault that is not mechanically related.
45	Hardware failure	Library magazine not present.

## Appendix B

# Regulatory Statements

---

---

## Battery Statement

---

**Caution**

The PMC contains a lithium battery that is replaceable only by qualified service personnel. If replacement is required, return the PMC to Sun or to an authorized Sun service center.

There is danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer.

---

## Additional Battery Statement

---

**Caution**

This product contains a Lithium battery. Lithium may be considered a hazardous material. Dispose of this battery in accordance with local, state, and federal laws.





# Glossary

---

---

## A

**Apply button** An on-screen button that allows changes to be made to the properties and attributes of a page or dialog box without closing it.

---

## B

**Banner frame** The browser frame that extends across the top of the screen which displays the corporate logo and software name.

---

## C

**community name** The administratively-assigned name of a logical management domain on a network as assigned by the system administrator. The community name is used as a selector by the agent to specify the access to local or remote management information and the context of the management information. The names “public” and “private” are common community names.

---

## D

**default gateway** The default gateway is the address through which IP packets will be routed if the system at the source address cannot communicate directly with the system at the destination address. Like the IP address, this is a 32-bit binary numeric address written as four decimal numbers separated by periods.

**DHCP** Dynamic Host Configuration Protocol. A protocol for assigning dynamic IP addresses on a network. With dynamic addressing, a device can have a different IP address each time it connects to the network.

**domain** In the Internet, a part of the naming hierarchy identifying a network or subnet. Syntactically, a domain name consists of a sequence of names (labels) separated by periods (dots).

---

**F**

**frame** A distinct and separate section of a Web page, commonly divided into a Banner frame, a Navigation frame, and a Management frame - each section acting as an independent browser window. The Banner frame commonly displays title information. The Navigation frame commonly displays headings which are linked to informational pages that display in the Management frame.

**Frame** Separate library modules connected through a common robot or elevator are considered frames. Each individual frame will have a unique identifier.

**FSE** Field Service Engineer. A representative of Sun Microsystems, Inc. trained and authorized to repair Sun products.

---

**H**

**hostname** The name of the server computer to which the library is attached.

**HyperTerminal** A 32-bit communications application, standard with Microsoft Windows, which provides asynchronous connectivity to host computers, such as online services or other PCs.

---

**I**

**IP address** The IP (Internet Protocol) address for the system. This is a 32-bit binary numeric address written as four decimal numbers separated by periods. For example, the binary address 11001111.11010011.11100000.00111011 is written as 207.211.224.59.

---

**K**

**key** A field used to sort data in database management systems.

- 
- L**
- LAN** Local area network. A network that connects computers that are close to each other, usually in the same building, linked by a cable.
- LUN** Logical unit number.
- 
- M**
- Management frame** The browser frame on the right of the screen which displays the active page.
- 
- N**
- Navigation frame** The browser frame on the left of the screen which displays a list of the Prism Management Console Web pages.
- 
- O**
- offline** A condition of the library in which the library is ready for communication with a diagnostic computer.
- OK button** Commits changes made to a dialog box and closes it.
- online** A condition of the library in which the library is ready for communications with a host.
- 
- P**
- page properties** The display and configuration attributes of a page.
- physical view** A graphical representation of the library that shows the tape drives, storage bins, and load ports together with their partition owners.
- PMC** Prism Management Card
- 
- R**
- reboot** The process of restarting a computer so the operating system is reloaded.
- Reset button** Returns the values in a dialog box to the default, or previously saved, values.
- restart** The process of restarting a computer without reloading the operating system.
- router** A device that governs the flow of traffic between networks or network segments and forwards packets between them, and converting between interfaces, such as SCSI, if necessary.

---

**S** **SCSI** Small Computer System Interface. A parallel interface standard used by many systems for attaching peripheral devices to computers.

**SCSI ID** A unique device identifier in the range of 0 to the maximum bus width that specifies a particular device on a given SCSI bus. If the bus width is 8, the range of SCSI IDs would be 0 to 7. Host computers typically reside at SCSI ID 7.

**SMTP** Simple Mail Transfer Protocol. A protocol used to transfer e-mail messages between computers.

**subnet mask** The subnet mask determines the subnet to which the IP address belongs. Like the IP address, this is a 32-bit binary numeric address written as four decimal numbers separated by periods.

---

**T** **trap** A program interrupt, usually caused by some exceptional situation in the user program. In most cases, the user performs some action, then returns control to the program.

---

**U** **URL** Uniform resource locator. A server address used by clients, such as Web browsers, to access information over the network using HTTP and other protocols.

---

**W** **Web browser** A client application that renders HTML code in a Graphical User Interface (GUI) and uses HTTP and other Internet protocols to communicate with Web servers. For example, Netscape Communicator and Internet Explorer are Web browsers.

# Index

---

---

## A

- Accessing
  - Help, on-line 6, 63
  - Prism Management Console 3–4
- Account, user
  - adding 12
  - deleting 14
- Activating a software image 17
- Adding
  - e-mail recipients 25
  - user accounts 12
- Administration
  - bridge 58
- ALERT E-mail 19–28
- ALERT Library Management 29–46

---

## B

- Banner frame 4
- Battery statements 95

## Bridge

- administration 58
- SCSI device 54
- status (Fibre Channel) 55, 58

---

## C

- Cartridge, moving 32
- Changer, SCSI device 54
- Changing
  - contact configuration 22
  - date and time settings 11
  - e-mail configuration 27
  - PMC network configuration 9
  - SCSI ID settings 37
- Contact configuration information, changing 22
- Contact Configuration page 20–22
- Contacting Sun Microsystems, Inc. 6

---

## D

- Date and Time Configuration page 10–11
- Date and time, changing 11
- Default settings, PMC 3
- Deleting
  - e-mail recipients 25
  - user accounts 14
- Drive status, viewing 33

---

## E

- E-mail Configuration page 26–28
- E-mail configuration, changing 27
- E-mail recipients
  - adding 25
  - deleting 25
  - viewing 24
- Event details listing 65–94
- Event History page 44–46

---

## F

- Fibre Channel 47
  - Loop ID 60
  - management 47
- Firmware, uploading 42
- Frames, page 4
- FSC code list 65–94

---

## H

- Help, accessing 6, 63

- Home page 4–6

---

## I

- Icon, status 5
- Initializing library statistics 41
- IP address, library 1

---

## L

- Library
  - IP address, determining 1
  - rebooting 17
  - self-test, performing 41
  - shutting down 18
  - status 5
- Library Configuration page 35–37
- Library Physical View 32
- Library Statistics page 38–40
- Library Status page 30–35
- Loop ID
  - setting 60

---

## M

- Management
  - Fibre Channel 47
- Message Configuration page 23–25
- Messages, status 5
- Monitoring Configuration page 43–44
- Monitoring interval, setting 43
- Moving a cartridge 32

---

**N**

Network Configuration page 8–9  
 Network configuration, PMC,  
 changing 9

---

**O**

On-line Help, accessing 6, 63

---

**P**

Page

Contact Configuration 20–22  
 Date and Time Configuration 10–  
 11  
 E-mail Configuration 26–28  
 Event History 44–46  
 Home 4–6  
 Library Configuration 35–37  
 Library Statistics 38–40  
 Library Status 30–35  
 Message Configuration 23–25  
 Monitoring Configuration 43–44  
 Network Configuration 8–9  
 route status 54  
 Service Operations 40–42  
 User Management 11–14  
 Utilities 15–18  
 Password, default 6  
 Physical View, Library 32  
 PMC  
 default settings 3  
 network configuration, changing 9  
 rebooting 17

shutting down 18

PMC Server Management 7–18

Prism

Fibre Channel management 47

Prism Management Console,  
 accessing 3–4

---

**R**

Rebooting, PMC and library 17

Recipients, e-mail

adding 25

deleting 25

viewing 24

Regulatory statements 95

Report, status, generating 44

Route status 54

---

**S**

SCSI ID settings, changing 37

Self-test, library, performing 41

Service Operations page 40–42

Settings

Loop ID (Fibre Channel) 60

Shutting down, PMC and library 18

Software image

activating 17

uploading 16

Statistics, library, initializing 41

Status

bridge (Fibre Channel) 55, 58

drive, viewing 33

library 5

report, generating 44

Sun Microsystems, Inc., contacting 6

---

## T

Tape

SCSI device 54

Tape cartridge, moving 32

Test e-mail, sending 28

---

## U

Uploading

firmware, library 42

software image 16

User account

adding 12

deleting 14

User Management page 11–14

User name, default 6

Utilities page 15–18

---

## V

Viewing

bridge status 55, 58

configuration

contact 20

e-mail 26

library 35

message 23

monitoring 43

network 8

date and time settings 10

e-mail recipients 24

event history 44

library statistics 38

status

drive 33

library 30

user accounts 11

---

## W

Weekly status report, generating 44